DECT 6.0 cordless telephone



# vtech Abridged user's manual (Canada version)

## Congratulations

on purchasing your new VTech product. Before using this telephone, please read Important safety instructions.

This abridged user's manual provides you with basic installation and use instructions. A limited set of features are described in abbreviated form. Please refer to the online user's manual for a full set of installation and operation instructions at www.vtechcanada.com



ephones identified with this log nave reduced noise and interference when used with most T-coil equipped aring aids and cochlear implants he TIA-1083 Compliant Logo is a rademark of the Telecommunications ndustry Association. Used under





he ENERGY STAR® program (www.energystar.gov) recognizes nd encourages the use of products that save energy and help protect out nvironment. We are proud to mark his product with the ENERGY STAR abel indicating it meets the latest energy efficiency guidelines.

# What's in the box

Your telephone package contains the following items. Save your sales receipt and original packaging in the event warranty service is








1 set for DS5151-2; 2 sets for DS5151-3



2 sets for DS5151-2; 3 sets for DS5151-3



## 2 - LCD display 3 - IN USE light

1 – Antenna

 On when the phone is in use, or when the answering system is answering an

Telephone base overview

- incoming call. · On when a handset is being registered.
- Flashes quickly when there is an incoming · Flashes when handsets are being
- deregistered. Flashes when another telephone on the
- 4 **▲**DIR
- Press to scroll up while in menus and lists. While entering or modifying names or numbers, press to move the cursor to the
- Press to review the directory.

## **▼**CID

- Press to scroll down while in menus and
- While entering or modifying names or numbers, press to move the cursor to the Press to view the caller ID log.
- **≪**/REPEAT During playback, press once to repeat the playing message.
- During playback, press twice to play the previous message

# Press **SELECT** on the telephone base to start

3. Press SELECT again to select LCD language

· It may be a wiring problem. If you have changed your telephone service to digital service from a cable company or a VoIP service provider, the telephone line may need to be rewired to allow all existing telephone jacks to

ollowing a power outage and battery depletion the handsets will prompt you to set the date and time. The telephone base will prompt you to set the date and time, and the answering system through voice guide

# Set date and time

recorded messages time stamp.

. Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press

choose AM or PM.

Press SELECT to save After the setting for the date and time, the

telephone base will display Voice guide to set up

This feature assists you to do the basic setup of the answering system. You can follow the voice guide to record your own announcement, set the number of rings and the message alert tone.

**⊘**NOTE

### the voice guide for the answering system setup. You hear the voice prompt "Hello! This voice" guide will assist you with the basic setup of your Set language

. Set up your answering system by inputting the designated numbers as instructed in the voice Check for dial tone

### telephone base. If you hear a dial tone, the installation is successful.

answerina svstem.

If you do not hear a dial tone: Make sure the installation procedures

his cordless telephone operates with the

Communications Commission (FCC). Even so, this

handset and telephone base can communicate

the locations of the telephone base and handset

When the handset is out of range, the handset

If there is a call while the handset is out of range,

If the handset moves out of range during a telephone

conversation, there may be interference. To improve

it may not ring, or if it does ring, the call may not

connect well when you press \ TALK . Move

reception, move closer to the telephone base.

Using the telephone base or

You can use the telephone base or a cordless

Press ▼ or ▲ until the screen displays the

• To return to the previous menu, press COFF on

the handset or CANCEL on the telephone base

To return to idle mode, press and hold OFF on

the handset or **CANCEL** on the telephone base.

handset to change vour telephone settings.

when it is not in use

desired feature menu.

3. Press **SELECT** to enter that menu.

answer the call.

displays Out of range OR No pwr at base.

over only a certain distance - which can vary with

the weather, and the layout of your home or office.

maximum power allowed by the Federal

Press **\TALK** on the handset or **■** on the

described above are properly done.

work. Contact your cable/VoIP service provider Set date and time for more information.

# Operating range

year correctly; otherwise the answering system does not announce the correct day of the week for you recorded messages time stamp

1. Press **MENU** when the handset or the telephone base is not in use.

(MM), date (DD) and year (YY). Then press

4. Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press ▼ or ▲ to closer to the telephone base, then press \TALK to choose AM or PM.

You can select the voice language (English or French) to be used for the voice prompts in the answering system and caller ID announce. base when the phone is not in use.

Press ▼ or ▲ to scroll to Settings, then press 3. Press **▼** or **△** to scroll to **Voice language**, then 1. Press **MENU** on the handset or telephone base press **SELECT**.

> Caller ID, then press SELECT. Press ▼ or ▲ to select English or Français. 6. Press **SELECT** to save and you hear a


## Press and hold to set and turn on the quiet mode, or turn it off.

· Press and hold to erase the missed call

· Press to silence the base ringer

indicator when the phone is not in use.

temporarily while the phone is ringing



andset overview

1 - Handset earpiece

is not in use.

group broadcast.

system devices

2 - LCD display

3 - MENU

13 - TONE X Press to switch to tone dialing during a call if you have pulse service.

 While entering names, press to change the next letter to upper or lower case.

14 – ▲ VOLUME ▼ During a call or message playback, press

to adjust the listening volume. · Press to adjust the telephone base ringer

volume when the base is not in use. 15 - Microphon

### 16 - Charging pole 17 - REDIAL/PAUSE

12 - OPER 0

 Press repeatedly to view the last 10 numbers dialed.

Press and hold to insert a dialing pause while dialing or entering numbers. 18 – Ø/HANDSET LOCATOR

 Press to page all handsets when the phone is not in use.

## 19 - PTT/FLASH

Press to initiate a one-to-one or one-togroup broadcast. Press and hold to broadcast to a group of

system devices. During a call, press to answer an incoming

While reviewing a caller ID log entry, press

signals. It automatically returns to pulse dialing

Telephone base control key panel:

node after you end the call.

Handset control key panel:

vtech

ors **7 |** TUV **8 |** WXYZ !

TONE X OPER O QUIET #

call when you receive a call waiting alert.

### repeatedly to add or remove 1 in front of the telephone number before dialing or

saving it in the directory. Press and hold to set or dial your voicemail Press and hold to set and turn on quiet

mode, or turn it off. · Press repeatedly to display other dialing

Press to show the menu when the phone

While in a menu, press to select an item,

Press and hold to broadcast to a group of

· Press to initiate a one-to-one or one-to-

While in a menu, press to cancel an

operation, back up to the previous menu or

exit the menu display; or press and hold to

Press and hold to erase the missed call

indicator when the phone is not in use.

temporarily while the phone is ringing

Press to silence the handset ringer

or save an entry or setting

Press to hang up a call.

go back to idle mode

options when reviewing a caller ID log entry.

# 

# Answer a call Press \TALK, ■® or any of the dialing keys on

# Press or any of the dialing keys on the

End a call

dial the number.

When you are using the base speakerphone,

## between the handset speakerphone and the handset earpiece.

 During a call, press ▲/VOLUME/▼ on the handset or telephone base to adjust the

party but the other party cannot hear you. handset displays **Muted** for a few seconds, and the **MUTE** icon displays on the handset until the

mute function is turned off.

2. Press **MUTE** on the handset again to resume the conversation. The handset displays Microphone ON briefly.

few seconds and the MUTE light turns on until the mute function is turned off 2. Press MUTE on the telephone base again to

displays Microphone ON briefly. Transfer a call While on an outside call, you can transfer the call

handset to another handset or the telephone base. 1. During a call, press **MENU**.

from the telephone base to a handset, or from a

# 3. Use the dialing keys to enter a specific device

Press repeatedly to view the last

Press 0 for the telephone base, 1-9 for

### 4. To answer the call on the destination device, press ►TALK, ■) or any dialing key on the nandset, or press ◀೨ or any dialing key on the

available

or to transfer a call.

10 numbers dialed.

# Join a call in progress

You can use the telephone base and a cordless handset, or two cordiess handsets at a time on an outside call.

 When a handset or the telephone base i already on a call, press **\TALK** or **◄**® on

### Press OFF or place the handset in the handset charger to exit the call. The call continues until both devices hang up.

## Press on the telephone base to exit the call. The call continues until both devices hang up.

## If you subscribe to call waiting service from your lephone service provider, you hear an alert

# tone when there is an incoming call while you are · Press FLASH on the handset or telephone

Press FLASH on the handset or telephone base to switch back and forth between calls. Find handset

## To start paging: • Press **HANDSET LOCATOR** on the

handset, press **\TALK**, ■ ) or any dialing key. telephone base and its screen displays Paging all handsets. All idle handsets ring To answer the intercom call at the telephone base, press or any dialing key. To end the intercom call on either handset, one

## Press **/HANDSET LOCATOR**, MUTE, or CANCEL on the telephone base.

### While entering or modifying names or numbers, press to move the cursor to the

Press to review the directory when the

Press to increase the listening volume

Press to scroll down while in menus and

· While entering or modifying names or

• Press to view the caller ID log when the

· Press to decrease the listening volume

when on a call, or to decrease the

message playback volume.

• On when the handset is charging.

numbers, press to move the cursor to the

when on a call, or to increase the message

phone is not in use.

playback volume.

phone is not in use.

VOLUME/▼CID

18 - CHARGE light

Charger overview

17 – ₩ **▲**/VOLUME

## Press to scroll up while in menus and lists. Handset display icons

ANS ON

splay icons overview

		desktop usage or wall mounting.
	The battery icon flashes when the battery is low and needs charging.	<ul> <li>NOTES</li> <li>Use only the adapters provided.</li> <li>Make sure the electrical outlets are wall switches.</li> <li>The adapters are intended to be considered a vertical or floor mount position. The designed to hold the plug in place in a ceiling, under-the-table or cabine.</li> </ul>
	The battery icon animates when the battery is charging.	
	The battery icon becomes solid when the battery is fully charged.	
	The speakerphone is in use.	
		1 '

The handset ringer is off.

swering system

the caller ID log.

Telephone base display icons

caller ID log

here are new voicemail received from

The answering system is turned on.

here is new message in the built-in

The entry you are reviewing is new in

The handset microphone is off.

The number of current playing

essages recorded

The telephone base ringer is off.

our telephone service provider

There are new voicemail received from

The entry you are reviewing is new in the

The total number of messages recorded

when the telephone base is not in use.

nessage and the total number of

our telephone service provider.

dapters are intended to be correctly oriented in ical or floor mount position. The prongs are no ned to hold the plug in place if it is plugged into ling, under-the-table or cabinet outlet


You can choose to connect the telephone base for

sure the electrical outlets are not controlled by


# If you subscribe to digital subscriber line (DSL)

nigh-speed Internet service through your telephone line, make sure you install a **DSL filter** (not included between the telephone line cord and telephone wall jack. Contact your DSL service provider for more


# Connect the telephone base





# Connect the charger




## Mount the telephone base










# nstall the battery


# Install the battery as shown below

Use only supplied battery.

Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual. If the handset will not be used for a long time,

disconnect and remove the battery to prevent possible





# Check the battery level

After you have installed the battery, check the battery level on the handset scree If the battery icon is □, □ or □, then go to

Before use section to set the date and time,

and set the answering system through voice

If the screen is blank, or [] flashes, then the battery needs to be charged. Go to Charge the battery section before you do any setting or

## Place the handset in the telephone base or handset charger to charge.

operations. You may use the handset which is put pick up the handset while using it.

Once you have installed the battery, the handset LCD display indicates the battery status (see the

## table below)

displays No battery

Press CANCEL or place the handset in the charger will bypass the set date and time. For best performance, keep the handset in the

The battery is fully charged after 12 hours of If you place the handset in the telephone base or the charger without plugging in the battery, the screen

telephone base or charger when not in use.

Battery indicators	Battery status	Action	
he screen blank, or splays <b>Place</b> charger nd [] flashes.	The battery has no or very little charge. The handset cannot be used.	Charge without interruption (at least 30 minutes).	
he screen splays ow battery nd [] flashes.	The battery has enough charge to be used for a short time.	Charge without interruption (about 30 minutes).	

The battery is

To keep the batter

charged, place it in

the telephone base

or charger when

When there is a power failure, all handsets display Put HS on base to power base and Out of range OR No pwr at base alternately. Put a charged handset in the telephone base to back up the telephone base power for some basic phone operations for a short period of time. During this period, you cannot use the answering system. When a handset is put in the telephone base, it displays Powering base... Don't pick up. At this time, use other handsets for some basic phone

## in the telephone base for making or answering calls via the handset speakerphone, but do not

When the cordless handset you put in the base does not have enough charge to back up the telephone base power, the handset displays Not enough batt to power base.

## efore use

After you install your telephone or power returns

Make sure you set the date and time including the vear correctly: otherwise the answering system does not announce the correct day of the week for your

# Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press ▼ or ▲ to

Set answering system through voice

# · This feature is only available in the telephone base.

## **▶**/SKIP

### Press to skip to the next message during message playback.

5 – ►/■/PLAY/STOP Press to start or stop message playback. 6 – 也/ANS ON/OFF

 Press to turn the built-in answering system on or off. 7 - MUTE/DELETE

 Press to mute the microphone during a · Press to silence the base ringer temporarily

when the phone is ringing. Press to delete the playing message or playing announcement.

Press to delete the displayed entry while reviewing the directory, caller ID log, redial list or call block list Press to delete digits or characters when

· Press twice to delete all old messages when the phone is not in use. 8 - **■** SPEAKER

entering numbers or names.

Press to make, answer or end a call. 9 - MENU/SELECT · Press to show the menu when the

operation, back up to the previous menu or

exit the menu display; or press and hold to

 While in a menu, press to select an item, or save an entry or setting 10 - CANCEL While in a menu, press to cancel an

telephone is not in use.

go back to idle mode.

# Temporary tone dialing

during a call.

21 - Speakerphone

The LCD language is preset to English. You can During a call, press TONEX. select English, French or Spanish to be used in all Use the dialing keys to enter the number you wish to dial. The telephone sends touch-tone

1. Press **MENU** when the handset or the elephone base is not in use. Press ▼ or ▲ to scroll to Settings, then press

## Press ▼ or ▲ to select English, Français or Español, then press SELECT twice to save your setting. You hear a confirmation tone.

If you accidentally change the LCD language to French or Spanish, you can reset it to English easily by pressing MENU then entering 364#.

Make sure you set the date and time including the

2. Press ▼ or ▲ to scroll to Set date/time, then press SELECT 3. Use the dialing keys (0-9) to enter the month

# 5. Press **SELECT**.

. Press **MENU** on the handset or the telephone

4. Press **▼** or **▲** to select **Answering sys** or **Annc** 

## If you have pulse (rotary) service only, you can switch from pulse to touch-tone dialing temporarily

the handset

Press COFF on the handset or place the handset in the telephone base or handset

Handset speakerphone During a call, press ■) on the handset to switch

# listening volume.

The mute function allows you to hear the other 1. During a call, press **MUTE** on the handset. The

1. During a call, press MUTE on the telephone base. The telephone base displays **Muted** for a

resume the conversation. The telephone base

2. Press **MENU** again to choose **Transfer**, the screen shows TRANSFER TO:.

· During an outside call, intercom call,

suit your hearing.

Microphone

message or announcement playback

press to change the audio quality to best

Press to mute the microphone during a call.

temporarily while the phone is ringing

Press to delete the displayed entry while

reviewing the directory, caller ID log or

Press to delete digits or characters when

• Press to delete the playing message or

During a call, press to switch between the

· Press to switch to tone dialing during a call

· While entering names, press to change the

next letter to upper or lower case.

Press to enter space during text editing.

While reviewing a caller ID log entry, press

repeatedly to add or remove 1 in front of

the telephone number before dialing or

Press and hold to set or dial your voicemail

During a call, press to answer an incoming

· During message playback, press to call

back the caller if the caller's number is

· Press to initiate or answer an intercom call.

Press and hold to insert a dialing pause

while dialing or entering numbers.

call when you receive a call waiting alert.

handset speakerphone and the handset

Press to silence the handset ringer

entering numbers or names.

Press to make or answer a call.

if you have pulse service

saving it in the directory.

Press to make or answer a call.

13 – 🖾 🕇

playing announcement

handsets 1-9, **TONE** followed by **0-2** for handsets 10-12, or **TONEX** followed by # for all devices.

# telephone base

# another handset to join the call.

Press 

on the telephone base to join the call.

base to put your current call on hold and take the new call.

This feature helps you find misplaced handsets.

To stop paging: Press **\TALK**, **■**)), or any of the dialing keys on the cordless handset.

Do not press and hold **MANDSET LOCATOR** 

make room for the new entry.

desired entry displays.

Delete a redial list entry

between two of your devices

phone is not in use.

then press **SELECT**.

press **DELETE**.

Review and dial a redial list entry

1. Press **REDIAL** when the handset or the

2. Press **▼**, **△** or **REDIAL** repeatedly until the

Press 

TALK or 

note
on the handset to dial.

Press • on the telephone base to dial.

Use the intercom feature for conversations

. Press INT on the cordless handset when the

Press **MENU** on the telephone base when it is

not in use. Press ▼ or ▲ to scroll to Intercom

. Choose the device(s) you would like to transfer

handsets 1-9, **TONEX** followed by **0-2** for

handsets 10-12, # for a single headset/

speakerphone, # followed by 1 or 2 for

headset/speakerphone 1 or 2, or TONEX

party presses **OFF**, or places the handset

back in the telephone base or handset charger.

To end the intercom call at the telephone base,

press CANCEL or press ◀೨ twice.

intercom call, you will hear an alert tone.

ntercom call

Answer an incoming call during an

If you receive an incoming outside call during an

Press 0 for the telephone base, 1-9 for

To answer the intercom call on the destination

followed by # for all devices.

While the screen displays the desired number,

telephone base is not in use.

1 – Charging pole

call ends automatically. Each handset and the telephone base store the To end the intercom call without answering last 10 telephone numbers dialed. When there are canceling the incoming call, press / OFF. The already 10 entries, the oldest entry is deleted to telephone continues to ring.

> Press ■. The intercom call ends automatically. Call transfer using intercom Use the intercom feature to transfer an outside call

To answer on a cordless handset

To answer at the telephone base:

To answer the call, press \\_TALK. The intercom

# to another cordless handset or the telephone base. 1. During a call, press **INT** on the handset.

During a call, press MENU on the handset or telephone base. Press ▼ or ▲ to scroll to press SELECT. Intercom, then press SELECT.

2. Choose the device(s) you would like to transfer Use the dialing keys to enter the number. Press 0 for the telephone base. 1-9 for handsets 1-9, TONEX followed by 0-2 for

speakerphone. # followed by 1 or 2 for headset/speakerphone 1 or 2. or **TONE** followed by # for all devices. 3. When the destination device picks up, the handset or telephone base shows **Interco**m Additional key presses show other characters

ou can transfer the call. Press **SELEC** twice to choose Transfer. The handset or telephone base shows **Call transferred**. The other device automatically connects to the outside call.

You can let the other device join you on the

pase. Press **\TALK** on your handset or press

and the outside call is put on hold. You have

the following options:

handsets 10-12, # for a single headset

outside call in a three-way conversation. Press MENU. Press ▼ or ▲ to highlight Share call, then press SELECT You can end the intercom call and continue the outside call with your handset or the telephone

# **CANCEL** on the telephone base.

ush-to-talk (PTT)

You can directly broadcast messages from one device to the speakerphone of one or a group of devices. To begin two-way communication, press **PTT** on the handset or the telephone base, and then select a device; or press and hold PTT on the

talk at a time. To do so, press and hold PTT.

group of devices. When the connection is made, both the initiating and the destination devices display Press and hold [PTT] to talk and beep once. Only one device can

# 

### The directory can store up to 50 entries, which are shared by all handsets and the telephone base. Each entry may consist of a telephone number with up to 30 digits and a name with up to 15 characters.

1. Enter the number when the phone is not in use. Press **MENU**, then go to Step 3.

Add a directory entry

i. Press MENU when the phone is not in use, then press ▼ or ▲ to scroll to **Directory**,

then press **SELECT**. ii. Press ▼ or ▲ to scroll to Add contact, then

epeatedly to find the desired number. Press

Copy a number from the redial list by pressing **REDIAL** and then press **▼**, **△** or **REDIAL** 

**SELECT** to copy the number. 3. Press SELECT to move on to enter the name. 4. Use the dialing keys to enter the name.

of that particular key.

5. Press **SELECT** to save. While entering names and numbers, you can: · Press DELETE to backspace and erase a digit

or character. Press and hold **DELETE** to erase the entire

Press ▼ or ▲ to move the cursor to the left or

## Press TONEX to change the next letter to upper or lower case.

Entries are sorted alphabetically

## handset or the telephone base to broadcast to a Dial a directory entry

When the desired entry appears Press **\TALK** or **◄** ) on the handset, or press

on the telephone base.

Press ♥ on the cordless handset or ▲DIR on

Press and hold **PAUSE** to insert a dialing pause (for entering numbers only).

Press **0** to add a space (for entering names

Review a directory entry

the telephone base when it is not in use.

2. Press ▼ or ▲ to browse through the directory, or use the dialing keys to start a name search

Telephone base control key panel:

### ,-----, Edit a directory entry

press **SELEC**1

- 2. Use the dialing keys to edit the number, then press SELEC1
- Use the dialing keys to edit the name, then
- Delete a directory entry
- When the desired entry appears, press **DELETE**. When the screen displays **Delete** contact?, press SELECT.

## peed dial

You can copy up to nine directory entries into the speed dial locations (0 and 2-9) so that you can

# Assign a speed dial number

dial these numbers more quickly.

- Press MENU on the handset or the telephone base when it is not in use . Press ▼ or ▲ to scroll to **Directory**, then press
- B. Press **▼** or **▲** to scroll to **Speed dial**, then press
- 4. Press  $\mathbf{V}$ ,  $\mathbf{\Delta}$  or a dialing key ( $\mathbf{0}$  or  $\mathbf{2}$ - $\mathbf{9}$ ) to choose

When the phone is not in use, press and hold

. Press ▼ or ▲ to scroll to **Directory**, then press

- the desired speed dial location Press SELECT. The screen displays Copy from Directory.
- 6. Press ▼ or ▲ to scroll to desired entry, then press SELECT

### a dialing key (0 or 2-9) on the handset or telephone base to dial the number stored in the corresponding speed dial location.

Dial a speed dial number

- Delete a speed dial number . Press **MENU** on the handset or the telephone base when it is not in use.
- B. Press **▼** or **△** to scroll to **Speed dial**, then press
- . Press **▼**, **△** or a dialing key (**0** or **2-9**) to choose the desired speed dial location, then press
- **SELECT** to show the speed dial entry. . Press **SELECT** again. Then press ▼ or ▲ to scroll to Clear SD and then press SELECT.

Press **DELETE** on the handset or telephone

## When the desired entry displays, press SELECT.

If you subscribe to caller ID service, information about each caller will appear after the first or second ring. If you answer a call before the caller's information appear on the screen, it will not be saved in the caller ID log.

The caller ID log stores up to 50 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name. If the phone number has more than 15 digits, only

the first 15 digits appear. If the name has more than 15 characters, only the first 15 characters are shown and saved in the caller ID log. Review a caller ID log entry

## 1. Press **▼CID** on the cordless handset or the

Caller ID

- telephone base when the phone is not in use 2. Press ▼ or ▲ to browse through the caller ID log.
- Missed call indicator When there are calls that have not been reviewed in the caller ID log, the screens display
- XX Missed calls Each time you review a caller ID log entry marked
- **NEW** on the handset or on the telephone base, the missed calls message goes away. If you do not want to review the missed calls one by one but still want to keep them in the caller ID g, press and hold **OFF** on the handset or CANCEL on the telephone base for four seconds
- when in idle mode. All the entries are then considered old. Dial a caller ID log entry

## When the desired entry displays, press \TALK or ■® on the handset to dial.

 When the desired entry displays, press ■ on the telephone base to dial. Save a caller ID log entry to the directory

3. Use the dialing keys to modify the name, if

- 1. When the desired caller ID log entry displays, press **SELECT**. If you are using the telephone base, you need to press **SELECT** again to
- 2. Use the dialing keys to modify the number, if necessary. Then press **SELECT**.

select Directory.

- necessary. Then press **SELECT**. Delete caller ID log entries When the desired caller ID log entry displays
- press **DELETE**. To delete all caller ID log entries 1. Press MENU on the handset or the telephone

To register HS.

nandset does not

I **see manual**. The

system does not

record messages.

I work at all.

- base when the phone is not in use. 2. Scroll to Caller ID log and then press SELECT
- Scroll to Del all calls then press SELECT twice.

If you subscribe to caller ID service, you can set the telephone to block unknown calls and certain undesired calls. The call block list can store up to 20 entries.

Call block

- This feature is only available in the telephone base Block unknown calls Press MENU on the telephone base when it is
- Scroll to Call block and then press SELECT. ring, or **Off** to keep the first ring. 3. Scroll to choose Calls w/o num, and then
- 4. Scroll to choose **Not block** or **Block**, and then

## press **SELECT** to save. Add a call block entry

- Press MENU on the telephone base when it is
- 2. Scroll to Call block and then press SELECT. Press SELECT to choose Block list.
- 4. Scroll to choose **Add new entry**, and then press **SELECT**. 5. Use the dialing keys to enter the number (up to
- 6. Press **SELECT** to move on to enter the name.
- 15 characters). Additional key presses show other characters of that particular key. 8. Press **SELECT** to save.

Use the dialing keys to enter the name (up to

### Review call block list . Press MENU on the telephone base when it is

Edit a call block entry

then press SELECT.

ystem does no

ounce the

veek for recorde

nessages time

The messages

system are

on the answering

accidentally set

change it back to

French, and I

rrect day of the

- not in use. 2. Scroll to Call block and then press SELECT.
- Press SELECT to choose Block list. Press SELECT to choose Review
- 1. When the desired entry displays on the telephone base, press SELECT 2. Use the dialing keys to edit the number, and
- 3. Use the dialing keys to edit the name, and then press **SELECT** to save.
- Save a caller ID log entry to call block list 1. When the desired caller ID log entry displays on the telephone base, press **SELECT**.
- 2. Scroll to Call block, and then press SELECT 3. Use the dialing keys to edit the number, and then press **SELECT**

the date and time. See

If a caller leaves a very

ong message, part o

disconnects the call afte

I the preset recording time

If the memory on the

becomes full during a

message, the answerin

system stops recording

and disconnects the ca

While the handset is not

then enter 364# to change

the handset LCD language

ny LCD language | in use, press **MENU** and

nportant safety instructions

precautions should always be followed to reduce the ris

When using your telephone equipment, basic safety

don't know how to back to English.

answering system

it mav be lost when

I the answering systen

Configure your telephon

4. Use the dialing keys to edit the name, and ther press **SELECT** to save.

# Your telephone rings once for blocked calls. You

can choose to mute the first ring for all incoming calls, so that there will be no ring for blocked cal By default, the mute first ring feature is set to Off. 1. Press **MENU** on the telephone base when it is

When the desired call block entry displays on

the telephone base, press **DELETE**.

- not in use. 2. Press 7464# on the telephone base. 3. Press ▼ or ▲ to choose On to mute the first
- 4. Press SELECT to save.
- When the telephone is ringing, you can temporarily • If you have muted the first ring, you will hear one silence the ringer without disconnecting the call. ring less before the answering system and voicemai The next call rings normally at the preset volume. answer the incoming calls To silence the handset ringer: Press MUTE or OFF on the handset and it

# ound settings

Delete a call block entry

## You can turn the kev tone on or off for each

Kev tone

- handset and the telephone base. . Press MENU on the handset or the telephone base when it is not in use. . Scroll to Settings and then press SELECT
- 3. Scroll to choose **Key tone**, then press **SELECT**. 4. Press ▼ or ▲ to select the desired volume or Off, then press SELECT to save.

# Ringer tone

- You can choose from different ringer tones for each handset and the telephone base. Press MENU on the handset or the telephone base when it is not in use.
- 2. Scroll to **Ringers** and then press **SELECT**. 3. Scroll to choose **Ringer tone**, then press
- 4. Press ▼ or ▲ to sample each ringer tone, then press **SELECT** to save.

## If you turn off the ringer volume on a cordless handset, you will not hear ringer tone samples

Telephone base ringer volume Press **▼/VOLUME/** on the telephone base to adjust the ringer volume when the telephone base is not in use

When you set the ringer volume to Off, the base ringer is off. The telephone base screen displays Caller ID won't be announced briefly, and then

## For pluggable equipment, the socket-outlet (power adapter) shall be installed near the equipment and

save. You hear a confirmation tone.

# CAUTION: Use Only Supplied Battery

- Do not open or mutilate the battery. Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if
- create a short circuit with conductive materials Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual.

### Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless

Wireless Technology Research, LLC (WTR), an

independent research entity, led a multidisciplinar evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers Supported by the U.S. Food and Drug Administration WTR recommends to physicians that: Pacemaker patients Should keep wireless telephones at least six inches from the pacemaker

- Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is
- Should use the wireless telephone at the ear opposite the pacemaker WTR's evaluation did not identify any risk to bystanders

### Privacy: The same features that make a cordless elephone convenient create some limitations

6. Only put the handset of your telephone next to your outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless nandset if the telephone base is unplugged, switched off or if the electrical power is interrupted. prongs are not designed to hold the plug in place if Potential TV interference: Some cordless t is plugged into a ceiling, under-the-table or cabinet telephones operate at frequencies that may cause

interference to televisions and VCRs. To minimize o

prevent such interference, do not place the telephor base of the cordless telephone near or on top of a T or VCR. If interference is experienced, moving the

bout the built-in answering

em and voicemail service

For message recording, your telephone has a

built-in answering system, and it also supports

service provider (subscription is required, and fee

the telephone base. I

will not be deleted

automatically. You

have to delete your

nessage manually.

When you received

ephone base both

o retrieve messages

►/■/PLAY/STOP

on the telephone

Access remotel

with an access

The answering system can record and store

to three minutes in length. The total storage

up to 99 messages. Each message can be up

capacity for the announcement, messages and

memos is approximately 23 minutes. The actual

recording time depends on individual message

characteristics.

t your built-in answering syste

sually there are tw

handset and the

display XX New

►/■/PLAY/STOP

liaht on the telepho

ase flashes.

Messages are stored | Messages are

stored in a

server or syste

our telephor

ervice provide

our messages

automatically

deleted after a

period of time.

Contact your

for more details

ssages, th

nandset and the

splay 🔀 and

ssages, vo

need an access

number and/c

ovided by

your telephon

service provide:

When you

nay be

voicemail service offered by your telephone

The main differences between them are:

may apply)

- ducting material such as rings, bracelets and key he battery or conductor may overheat and cause harm. Observe proper polarity between the battery Nickel-metal hydride rechargeable batteries
- ົໄhe RBRCຶ seal

## The RBRC® seal on the nickel-metal hydride battery

out of service within the United States and Canada. The RBRC® program provides a convenient alternative to placing used nickel-metal hydride batteries into the trash or municipal waste, which may be illegal in your area VTech's participation in BBBC® makes it easy for you to drop off the spent battery at local retailers participating service centers. Please call 1 (800) 8 BATTERY® for information on Ni-MH battery recycling and disposal environment and conserving natural resources. RBRC® and 1 (800) 8 BATTERY® are registered trademarks of the Rechargeable Battery Recycling



## Press 5 to stop playback

Options during playback:

# FCC, ACTA and IC regulations

Your answering system allows you to set your

activate call screening, to set number of rings

CANCEL MENU

Turn the answering system on or off

The answering system must be turned on to

Press **U/ANS ON/OFF** on the telephone base

to turn the built-in answering system on or off.

. Press **MENU** on the handset or the telephone

Scroll to Answering sys, then press SELECT.

. Press **▼** or **△** to choose **On** or **Off**, then press

The telephone is preset with a greeting that

message after the tone." You can use this preset

The announcement can be up to 90 seconds in

Press MENU on the handset or the telephone

Press SELECT again to select Record annc

Scroll to Answering sys, then press SELECT

the system announces, "Record after the tone.

Press 5 when you are done." After the tone,

Press **MENU** on the handset or the telephone

2. Scroll to **Answering sys**, then press **SELECT** 

Press **▲/VOLUME/**▼ on the cordless handset,

or on the telephone base to adjust the listening

answers calls with, "Hello. Please leave a

announcement, or replace it with your own.

Record your own announcement

base when the phone is not in use.

speak towards the microphone

base when the phone is not in use.

Scroll to Play annc, then press SELECT

Play your announcement

Press 5 when done.

Scroll to Answer ON/OFF, then press SELECT

answer and record messages

base when it is not in use.

Default announcement

the recording time

announcement, to save and delete messages,

before pick up, to access remotely, and to control

, - - - - - - - - - - - - - - - - - -

**-/** 

(b)

MUTE

Telephone base control key pane

### to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications sion (FCC) rules. These requirements are intended to provide reasonable protection against harm interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio ications. However, there is no guarantee tha interference will not occur in a particular installation. If th equipment does cause harmful interference to radio or

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit
- technician for help

be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteri The handset may be safely held against the ear of the user. The telephone base shall be installed and used such that parts of the user's body other than the han are maintained at a distance of approximately 20 cm (8 inches) or more.

adopted by ACTA. A compliant telephone cord and

evision reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Increase the separation between the equipment and
- Consult the dealer or an experienced radio/TV
- WARNING: Changes or modifications to this equipmen

(2) this device must accept any interference received including interference that may cause undesired operation. Privacy of communications may not be ensured when using this telephone.

This Class B digital apparatus complies with Canadian requirement:

CAN ICES-3 (B)/NMB-3(B).

rules and with technical requirements adopted by the ninistrative Council for Terminal Attachments (ACTA) The label on the back or bottom of this equipment contains, among other things, a product identifier in the provided to your telephone service provider upon request The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with applicable Part 68 rules and technical requirements

### Scroll to Ans sys setup, then press SELECT. 4. Scroll to # of rings, then press SELECT.

here are no new messages

Set number of rings

Delete your announcement

base when the phone is not in use

3. Scroll to Play annc, then press SELECT

While the announcement is playing, press

When your announcement is deleted, calls are

You can set the answering system to answer an

or select toll saver. If you choose toll saver, the

incoming call after two, three, four, five or six rings:

answering system answers a call after two rings if

Press **MENU** on the handset or the telephone

you have new messages, or after four rings wher

2. Scroll to Answering sys, then press SELECT

base when the phone is not in use.

Press ▼ or ▲ to select 2, 3, 4, 5, 6 or

Toll saver, and then press SELECT

answered with the default announcement.

. Press **MENU** on the handset or the telephone

Scroll to Answering sys, then press SELECT

**DELETE** to delete your recorded announcement.

ring less before the answering system answers the incoming calls. Set recording time

If you have muted the first ring, you will hear one

- You can set the recording time allowed for each incoming message 1. Press MENU on the handset or the telephone
- base when the phone is not in use. 2. Scroll to Answering sys, then press SELECT Scroll to Ans sys setup, then press SELECT
- 4. Scroll to **Recording time**, then press **SELECT**. 5. Press **▼** or **△** to select **3 minutes**, **2 minutes** or 1 minute, and then press SELECT.

Turn the message alert tone on or off

When the message alert tone is set to on, and there is at least one new message, the telephone base beeps every 10 seconds. The message alert tone is preset to off

## There is no audible alert at the handse Press MENU on the handset or the telephone

- base when the phone is not in use. 2. Press ▼ or ▲ to scroll to Answering sys, then press **SELECT**
- 3. Press ▼ or ▲ to scroll to Ans sys setup, then press **SELECT**
- 4. Press **▼** or **△** to scroll to **Msg alert tone**, then press **SELECT**.
- Press ▼ or ▲ to select On or Off.
- to be connected to a compatible modular jack that is also

ee the installation instructions in the user's manual.

compliant. An RJ11 jack should normally be used for necting to a single line and an RJ14 lack for two lines.

NOTE: This equipment has been tested and found

different from that to which the receiver is connected.

not expressly approved by the party responsible for

To ensure safety of users, the FCC has established

FCC Part 68 and ACTA

equipment is 1.0. The REN indicates the maximum number of devices allowed to be connected to a elephone interface. The termination of an interface may consist of any combination of devices subject only to the guirement that the sum of the RENs of all the devices not exceed five.

What does this limited warranty cover?

America and Canada.

6. Press **SELECT** to save and you hear a

nessage alert tone to be functional.

The answering system must be turned on for the

This feature is an alternative way for you to do the

the voice guide to record your own announcement

basic setup of the answering system. You can follow

set the number of rings and the message alert tone.

This feature is only available in the telephone base

1. Press **MENU** on the telephone base when it is

Scroll to Answering sys, then press SELECT

You hear the voice prompt "Hello! This voice

guide will assist you with the basic setup of your

designated numbers as instructed in the voice

Use your built-in answering systen

When there are new answering system messages,

New messages, and the ►/■/PLAY/STOP light on

the handset and the telephone base display XX

elephone base beeps every 10 seconds when

here are messages that have not been reviewed.

Press ►/■/PLAY/STOP when the phone is not

1. Press **MENU** when the phone is not in use.

Press **SELECT** to select **Play messages**.

If there are new and old messages, scroll to

select Play new msgs or Play old msgs,

Press **▲/VOLUME/**▼ to adjust the message

Press ►/SKIP to skip to the next message.

Press **≪/REPEAT** twice to hear the previous

and then press SELECT or ▶/■/PLAY/STOP

If the message alert tone is turned on, the

To play messages at the telephone base:

3. Scroll to **Voice guide**, then press **SELECT**.

4. Set up your answering system by inputting

New message indication

Message playback

Options during playback:

olayback volume

message

/HANDSET LOCATOR) to temporarily silence

Press any key on the telephone base (except

confirmation tone.

the message alert tone.

Voice guide

This product meets the applicable Innovation, Science nd Economic Development Canada technical specifications.

The manufacturer of this VTech Product warrants to the

holder of a valid proof of purchase ("Consumer" or "vou")

that the Product and all accessories provided in the sales

package ("Product") are free from defects in material

and workmanship, pursuant to the following terms and

ordance with the Product operating instructions

What will VTech do if the Product is not free from

defects in materials and workmanship during

he limited warranty period ("Materially Defective

During the limited warranty period, VTech's authorized

service representative will repair or replace at VTech's

option, without charge, a Materially Defective Product.

replacement parts. If we choose to replace the Product

nodules, or equipment. Repair or replacement of the

roduct, at VTech's option, is your exclusive remedy.

he limited warranty period for the Product extends

you in working condition. You should expect the repair or

e may replace it with a new or refur

replacement to take approximately 30 days.

How long is the limited warranty period?

What is not covered by this limited warranty

Product that has been subjected to misuse, accident.

alteration or modification by anyone other than an

This limited warranty does not cover:

conditions, when installed and used normally and in

## How do you get warranty service website at www.vtechcanada.com or call

**NOTE:** Before calling for service, please review the user's manual - a check of the Product's controls and

Except as provided by applicable law, you assume the his limited warranty extends only to the Consumer fo oducts purchased and used in the United States of

> nage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request

## 1. Return the entire original package and contents ncluding the Product to the VTech service location

- the date of purchase or receipt; and 3. Provide your name, complete and correct mailing address, and telephone number
- Other limitations This warranty is the complete and exclusive agreement

warranty service?

The warranty exclusively describes all of VTech's other express warranties. No one is authorized to make modifications to this limited warranty and you should not ely on any such modification State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

(during playback).

\*5 Hear a list of remote commands. \*7 Record a new announcement. 8 End the call 0 Turn the answering system on or off.

4. Hang up or press 8 to end the call.

Set your remote access code You can set your own remote access code from

1. Press **MENU** on the handset or the telephone Press 4 to repeat the message. Press 4 twice base when the phone is not in use

Scroll to Answering sys. then press SELECT Press **DELETE** to delete the playing message 3. Scroll to Ans sys setup, then press SELECT.

> 4. Scroll to **Remote code**, then press **SELECT** 5. Press ▼ or ▲, or use the dialing keys (0-9) to

enter a two-digit number. Press **DELETE** on the handset or telephone

voicemail message.

appropriate setting.

base to backspace and delete a digit. You cannot delete new messages until you review 6. Press **SELECT** to save and you hear a

**Use the built-in answering systen** nd voicemail service

You can use your answering system and voicemail

service together by setting your answering system

to answer before voicemail service answers as

described below. To learn how to program your voicemail settings, contact your telephone service If you are on a call, or if the answering syster is busy recording a message and you receive another call, the second caller can leave a

Set your answering system to answer calls a least two rings earlier than your voicemail is set to answer. For example, if your voicemail answers after six rings, set your answering system to nay program the delay before answering calls n seconds instead of rings. In this case, allow six seconds per ring when determining the

proof of purchase

Transmit Handset frequency 1921.536-1928.448 MHz Telephone base 1921.536-1928.448 MHz Channels 5

### Turn off the new voicemail indicator If you have retrieved your voicemail while away from home, and the telephone still displays the new voicemail indicators, use this feature to turn

service provider (up to 30 digits) when prompted.

 This feature turns off the indicators only, it does not delete your voicemail messages

base when it is not in use.

off the indicators.

3. Press **SELECT** to save.

Expand your telephone system You can add new handsets (DS5101), cordless headsets (IS6200) or speakerphones (MA3222 or AT&T TL80133) to your telephone system. All accessories are sold separately. Your telephone

base supports a maximum of 12 devices.

comes with your new device.

For more details, refer to the user's manual that

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base. with your telephone service, or may be optional.

### Retrieve voicemail When you received a voicemail, the handset and the telephone base display and New voicemail

To retrieve, you typically dial an access number

telephone service providers. It may be included

Voicemail is a feature available from most

trieve voicemail from telephor

provided by your telephone service provider, and then enter a security code. Contact your telephone service provider for instructions on how to configure the voicemail settings and listen to messages.

messages, the indicators on the handset and the elephone base turn off automatically Set your voicemail number You can save your access number on each handse

After you have listened to all new voicemail

you can press and hold 1 to retrieve voicemail . Press and hold **1** on the handset or the telephone base when it is not in use. 2. Use the dialing keys to enter the voicemail

access number provided by your telephone

and the telephone base for easy access to your

voicemail. After you saved the voicemail number

. Press **MENU** on the handset or the telephone

2. Scroll to **Settings**, then press **SELECT**. 3. Scroll to CIr voicemail, then press SELECT. 4. Press **SELECT** again to confirm.

eneral product care

Avoid rough treatment Place the handset down gently. Save the original

Your telephone can be damaged if it gets wet. Do

not use the handset outdoors in the rain, or handle

surges harmful to electronic equipment. For your

own safety, take caution when using electrical

it with wet hands. Do not install the telephone base near a sink, bathtub or shower. Electrical storms

# Cleaning your telephone

My telephone

dampened cloth or cleaning solvents of any kind. requently asked questions

and battery is installed

### Taking care of your telephone Your cordless telephone contains sophisticated electronic parts, so it must be treated with care.

packing materials to protect your telephone if you ever need to ship it.

Electrical storms can sometimes cause power

### Your telephone has a durable plastic casing tha should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use

Below are the questions most frequently asked about the cordless telephone. If you cannot find the answer to your question, visit our website at www.vtechcanada.com or call 1 (800) 267-7377

Make sure the telephone does not work at base is installed properly

and charged correctly. For optimum daily performance, return the handset to the telephone base after use.

### The display shows | Disconnect the telephone **No line.** I cannot line cord from your near the dial tone. telephone and connect it to nother telephone. If there

s no dial tone on that other elephone either, then the elephone line cord may be defective. Try installing a new telephone line cord. If changing the telephone line cord does not help, the wall jack (or the wirir to this wall jack) may be

defective. Contact you telephone service provide You may be using a new cable or VoIP service. the existina telephone iacks i vour home mav no longe work. Contact vour service provider for solutions.

he display shows | The handset is I deregistered from the telephone base. Place the handset in the

## You hear a beep when the registration process takes about 60 seconds. Make sure the answering system is on. When the

telephone base to registe

the handset and the

When the answering

machine memory is ful

it does not record new

messages until some old

voicemail service, change

the number of rinas so

svstem answers before

vour voicemail service

answers. To determine hov

many rings activate your

voicemail service, contact

your telephone service

provider.

that your answering

messages are deleted.

If you subscribe to

of fire, electric shock and injury, including the following: Read and understand all instructions answering system is or Follow all warnings and instructions marked on the ANS ON should display o Unplug this product from the wall outlet before **ປ/ANS ON/OFF** light on the telephone base should

cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning. Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub or wimming pool, or in a wet basement or shower Do not place this product on an unstable table, shelf,

Avoid placing the telephone system in places with extreme temperature, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids and fumes. Slots and openings in the back or bottom of the elephone base and handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product

on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a adiator or heat register. This product should not b placed in any area where proper ventilation is not

This product should be operated only from the type

of power source indicated on the marking label. If

you are not sure of the type of power supply in your

# home or office, consult your dealer or local power Do not allow anything to rest on the power cord

 Never push objects of any kind into this product through the slots in the telephone base or handset because they may touch dangerous voltage poir or create a short circuit. Never spill liquid of any kind on the product. To reduce the risk of electric shock, do not

Do not install this product where the cord may be

arts of the telephone base or handset othe than specified access doors may expose you to dangerous voltages or other risks. Incorrect mbling can cause electric shock when th product is subsequently used. Do not overload wall outlets and extension cords.

disassemble this product, but take it to an

authorized service facility. Opening or removing

ollowing conditions When the power supply cord or plug is damaged

 If liquid has been spilled onto the produce If the product has been exposed to rain or water. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation

extensive work by an authorized technician to

estore the product to normal operation. If the product has been dropped and the telephone base and/or handset has been damaged.

ear when it is in normal talk mode.

. The power adapters are intended to be correctly

oriented in a vertical or floor mount position. The

shock from lightning. 5. Do not use the telephone to report a gas leak in the with pacemakers from other persons using wireless ricinity of the leak. Under certain circumstance a spark may be created when the adapter is plugged into the power outlet, or when the handset s replaced in its cradle. This is a common event associated with the closing of any electrical circuit e user should not plug the phone into a powe outlet, and should not put a charged handset into the cradle, if the phone is located in an environment supporting gases, unless there is adequate ventilation. A spark in such an environment could reate a fire or explosion. Such environments might

shall be easily accessible. **SAVE THESE INSTRUCTIONS** 

Handset ringer volume

base when it is not in use

then press **SELECT** to save.

Temporary ringer silencing

displays **Ringer muted** and  $\searrow$ .

To silence the telephone base ringer

Press MUTE or CANCEL on the telephone

base and it displays **Ringer muted** and  $\lambda$ .

You can turn on quiet mode for a period of time

paging tone) and call screening are muted

To set and turn the quiet mode on

To turn the guiet mode off:

the audio to best suit your hearing

message or announcement:

press SELECT

QUIET#

Equalizer

(1-12 hours). During this period, all tones (except

Press and hold QUIET# on the handset or the

phone base when it is not in use.

While the quiet mode is on, press and hold

The equalizer enables you to change the quality of

While on a call or intercom call, or listening to a

equalizer setting Treble 1, Treble 2, Bass

or **Natural** (the default setting). The current

setting is shown on the handset screen for two

• Press **EQ** on the handset to select the

1. Press **MENU** on the telephone base.

2. Press ▼ or ▲ to scroll to Equalizer, then

Press ▼ or ▲ to select the equalizer setting

default setting), and then press **SELECT** to

Treble 1, Treble 2, Bass or Natural (the

2. Use the dialing keys to enter the desired

duration (1-12), then press **SELECT**.

turn the ringer off.

You can adjust the handset ringer volume level, or

. Press **MENU** on the handset or the telephone

Scroll to Ringers and then press SELECT twice.

Press ▼ or ▲ to sample each volume level.

When the ringer volume is set to off,

the handset still rings when you press

/HANDSET LOCATOR at the telephone

servicing to an authorized service facility under the

nstructions. Improper adjustment of other controls may result in damage and often requires

 If the product exhibits a distinct change in performance. 14. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric

include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.

Do not dispose of the battery in a fire. Check with local waste management codes for special disposal

Exercise care in handling batteries in order not to

Unplug this product from the wall outlet and refer

# About cordless telephones

elephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless elephone conversations could be intercepted by adio receiving equipment within range of the cordless nandset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones. **Electrical power:** The telephone base of this cordless elephone must be connected to a working electrical

cordless telephone farther away from the TV or VCR often reduces or eliminates the interference. Rechargeable batteries: Exercise care in handling batteries in order not to create a short circuit with

### Dispose of these batteries in a safe manner. Do no irn or puncture the battery. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.

indicates that VTech Communications. Inc. is voluntarily participating in an industry program to collect and recycle hese batteries at the end of their useful lives, when taken

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1

less. For more information, contact your telephone service

compliance could void the user's authority to operate the

This equipment complies with Part 68 of the FCC

ormat US:AAAEQ##TXXXX. This identifier must be

modular plug is provided with this product. It is designed

### The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are ed. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most. bu

This equipment must not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If yo have questions about what will disable alarm equipmen consult your telephone service provider or a qualified

If this equipment is malfunctioning, it must be unplugged

corrected. Repairs to this telephone equipment can only

be made by the manufacturer or its authorized agents

from the modular jack until the problem has been

or repair procedures, follow the instructions outlined under the Limited warranty If this equipment is causing harm to the telephone etwork, the telephone service provider may temporarily scontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practica will be notified as soon as possible. You will be give he opportunity to correct the problem and the telephone service provider is required to inform you of your right provider may make changes in its facilities, equipment operation, or procedures that could affect the proper

If this product is equipped with a corded or cordless handset, it is hearing aid compatible If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.g.

unctioning of this product. The telephone service

provider is required to notify you if such changes are

morning or late evening **Industry Canada** This device complies with Industry Canada licence-

call before hanging up.

exempt RSS standard(s)

specifications were met.

this device must accept any interference received ncluding interference that may cause undesired Privacy of communications may not be ensured when using this telephone.

The Ringer Equivalence Number (REN) for this terminal

The term "IC:" before the certification/registration

Operation is subject to the following two conditions: (1)

s device may not cause harmful interference, and

for ONE (1) YEAR from the date of purchase. If VTech police. fire, medical) in these locations. If you do store or epairs or replaces a Materially Defective Product under emergency numbers, please the terms of this limited warranty, this limited warranty also applies to the repaired or replacement Product fo Remain on the line and briefly explain the reason for the a period of either (a) 90 days from the date the repaire or replacement Product is shipped to you or (b) the time Perform such activities in off-peak hours, such as early remaining on the original one-year warranty; whichever

> shipping or other physical damage, improper installation, abnormal operation or handling, neglect inundation, fire, water or other liquid intrusion; or 2. Product that has been damaged due to repair.

authorized service representative of VTech; Product to the extent that the problem experienced s caused by signal conditions, network reliability, or number only signifies that the Industry Canada technical cable or antenna systems; 4. Product to the extent that the problem is caused by

use with non-VTech accessories;

been removed, altered or rendered illegible; . Product purchased, used, serviced, or shipped fo repair from outside the United States of America or Canada, or used for commercial or institutional

Press DELETE to delete the playing message.

The system advances to the next message.

Press ►/■/PLAY/STOP to stop the playback.

1. Press **MENU** when the phone is not in use

• If there are new and old messages, scroll to

select Play new msgs or Play old msgs,

Press ▲/VOLUME/▼ to adjust the message

• Press **EQ** to adjust the message playback

The system advances to the next message.

Press 5 or **OFF** to stop the playback.

You can only delete old (reviewed) messages

them. You cannot retrieve deleted messages.

To delete all messages with the telephone

• Press **DELETE** twice when in idle mode.

To delete all old messages with a handset

3. Scroll to **Delete all old**, and then press

1. Press **MENU** when the phone is not in use

2. Scroll to Answering sys, then press SELECT.

A two-digit security code is required to access the

telephone. The preset code is **19**. You can use this

answering system remotely from any touch-tone

. Dial your telephone number from any touch

2. When the system plays your announcement,

3. Enter one of the following remote commands

lavback).

5. Product whose warranty/quality stickers, product

Play all messages.

Play only new messages

Delete all old messages

(during playback).

Delete the current message (durin

Repeat the current message

enter the two-digit security code.

Press 6 to skip to the next message

to hear the previous message

Delete all old messages

**SELECT** twice.

preset code, or set your own

tone telephone.

Remote access

Press SELECT to select Play messages.

To play messages with a handset:

and then press **SELECT** 

Options during playback

plavback volume.

audio quality

7. Product returned without a valid proof of purchase (see item 2 below); or . Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

or rental purposes

To obtain warranty service in Canada, please visit our

risk of loss or damage during transit and transportation ocurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery o handling charges are prepaid. VTech assumes no risk for

features may save you a service call.

repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are What must you return with the Product to get

along with a description of the malfunction or difficulty; 2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and

between you and VTech. It supersedes all other ritten or oral communications related to this Product.

VTech provides no other warranties for this Product.

serial number plates or electronic serial numbers have for a particular purpose and merchantability (an unwritter warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long implied warranty lasts, so the above limitation may no purposes (including but not limited to Products used apply to you. In no event shall VTech be liable for any ndirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated by third parties) resulting from the use of this Product Some states/provinces do not allow the exclusion or

Caller ID log:

50 memory locations up to 24 digits and 15 characters Call block: 20 entries

© 2016 for VTech Technologies Canada Ltd. All rights reserved. 05/16. DS5151-X\_CA\_ACIB\_V1.0 Document order number: 91-010037-010-100

Handset requirement 2.4V Ni-MH battery Telephone base: 6V DC @ 600mA

> 50 memory locations up to 30 digits and 15 characters

the time of use.

Memory Directory:

Specifications are subject to change without notice

equipment, the cost of substitute equipment, and claim imitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Please retain your original sales receipt as

Limitations: Implied warranties, including those of fitness

chnical specifications requency Crystal controlled PLL synthesize

Maximum power allowed by FCC and IC. Actual operating range may vary

6V DC @ 400mA