Go to www.vtechcanada.com
for the latest VTech product news.

RM7766HD
RM7766-2HD

7" Smart Wi-Fi 1080p
Pan & Tilt Monitor

For more support information

vtech®

Quick start guide
(Canada version)

Congratulations

on purchasing your new VTech product.
Before using this baby monitor, please read the **Important safety instructions**.

What does HD Video Monitor do?

VTech 7" Smart Wi-Fi 1080p Pan & Tilt Monitor allows you to stay close to your baby when you are on the move or away. This monitor is Wi-Fi enabled, using your home wireless network to stream live video and audio through the 1080p baby unit and 7-inch color screen parent unit. It allows you to maintain a constant connection to your baby.

You can also monitor from your smartphone and mobile tablet.

VTech 7" Smart Wi-Fi 1080p Pan & Tilt Monitor uses **MyVTech Baby Pro** app to let you instantly see and hear what's happening with your baby from anywhere in the world. The app can be downloaded from the App Store or the Google Play™ Store.

IMPORTANT SAFETY INSTRUCTIONS

The applied nameplate is located at the bottom of the baby unit's base. When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

1. Follow all warnings and instructions marked on the product.
2. Adult setup is required.
3. **CAUTION:** Do not install the baby unit at a height above 6.5 feet (2 meters).
4. This product is intended as an aid. It is not a substitute for responsible and proper adult supervision and should not be used as such.
5. This product is not intended for use as a medical monitor.
6. Do not use this product near water, for example, near to a bath, sink, swimming pool or shower.
7. **CAUTION:** Use only the battery provided (if applicable). There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery in fire or a hot oven, mechanically crushing or cutting the battery can result in an explosion. Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the information in **The RBRC seal**.
8. Use only the adapters included with this product. Incorrect adapter polarity or voltage can seriously damage the product.

Power adapter information:
Baby Unit Output: 5V DC 1000mA
VTech Telecommunications Ltd.
Model: VT0SEUS05100
Parent Unit Output: 5V DC 2A
VTech Telecommunications Ltd.
Model: VT0TEUS05200

Rechargeable battery information:
3.7V 5000mAh,18.5Wh Lithium-ion battery
Zhuhai Great Power Energy Co., Ltd.
Model: GSPB06090-SAh-3.7V-1S1P

9. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.
10. For pluggable equipment, the socket-outlet (power adapter) shall be installed near the equipment and shall be easily accessible.
11. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
12. Do not modify the power adapters or replace with other adapters, as this causes a hazardous situation.
13. Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or crimped.
14. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home, consult your dealer or electricity supply provider.
15. Do not overload wall outlets or use an extension cord.
16. Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
17. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register.
18. Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the

product.
19. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Disassembling or removing parts of the product other than via the battery door (if applicable) may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.
20. You should test the sound reception every time you turn on the units or move one of the components.
21. Periodically examine all components for damage.
22. There is a very low risk of privacy loss when using certain electronic devices, such as baby monitors, cordless telephones, etc. **To protect your privacy, make sure the baby monitor has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you will not use it for some time.**
23. Children should be supervised to ensure that they do not play with the product.
24. The small parts of this monitor can be swallowed by babies or small children. Keep these parts out of reach of children.
25. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SAVE THESE INSTRUCTIONS

Cautions
- Use and store the product at a temperature between 32°F and 104°F.
- Mishandling batteries can cause burn, fire or explosion hazards.
- Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source.
- ⚠ Warning—Strangulation Hazard—Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9m) away). Do not remove warning label on the adapter cord.
- Never place the camera unit(s) inside the baby's crib or playpen. Never cover the camera unit(s) or parent unit with anything such as a towel or a blanket.
- Other electronic products may cause interference with your camera unit. Try installing your camera unit as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and cordless telephones.

Precautions for users of implanted cardiac pacemakers
Cardiac pacemakers (applies only to digital cordless devices): Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:

Pacemaker patients
- Should keep wireless devices at least six inches from the pacemaker.
- Should NOT place wireless devices directly over the pacemaker, such as in a breast pocket, when it is turned ON.
WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices.

Electromagnetic fields (EMF)
This VTech product complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the product is safe to be used based on scientific evidence available today.

WHAT'S IN THE BOX

Your baby monitor package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.

Quick start guide

x 2   x 2

1 set for RM7766HD
2 sets for RM7766-2HD

Requirements

For mobile access:

MyVTech Baby Pro mobile app	
Network	Wi-Fi
Wi-Fi router	2.4GHz 802.11 b/g/n
Internet connection	1.5 Mbps @720p or 2.5 Mbps @1080p upload bandwidth per baby unit

DOWNLOAD APP FOR MOBILE ACCESS

1 Download the free **MyVTech Baby Pro** mobile app and install it to a mobile device, then use your mobile device and the mobile app to monitor your areas remotely.

1. Press **MENU** when the parent unit is idle.
2. Go to ⚙ > **Connect Mobile Phone**.
3. Scan the QR code in the parent unit to download the app into your mobile device.
4. Follow the instructions in the mobile app to set up and pair your baby unit to the mobile app.

Alternatively, you can download the mobile app from the App Store or Google Play store.

Install MyVTech Baby Pro mobile app
1. Browse the App Store or the Google Play store.
2. Search for the mobile app with the keyword "myvtech baby pro".
3. Download and install the **MyVTech Baby Pro** mobile app to your mobile device.
OR
Scan the QR codes on the right to get the app.

Note
- Make sure your mobile device meets the minimum requirement for the mobile app.

Minimum requirement
The mobile app is compatible with:
- Android™ 6.0 or later; and
- iOS 12 or later.

2 After installing the mobile app, follow the instructions in the mobile app and parent unit to set up and pair your baby unit.

In your mobile device:
1. Tap to run the mobile app in your mobile device, and then create a user account.
2. We recommend that you use common webmail services, such as Google Gmail for registration of your user account. Check your email (and Spam folder), and activate your new camera account via the email link, then sign in to your account.
3. Follow the instructions in the mobile app to pair the camera. Tap ☰, then **Add Camera** in the mobile app to get started.

OVERVIEW

Baby unit overview

1. **Light sensor**
2. **Camera lens**
3. **Infrared LEDs**
   - Allow you to see clearly in a dark environment.
4. **Microphone**
5. **Night Light**
6. ☼ **Night Light Control Key**
   - Go to **Night Light** section to learn more.
7. **LED indicator**
   - Red is steadily on when the baby unit is connecting to the parent unit in direct mode.
   - Green is steadily on when the baby unit is connected in Wi-Fi router mode.
   - Red flashing slowly during video streaming in direct mode.
   - Green flashes slowly during video streaming in Wi-Fi router mode.
8. **ON/OFF switch**
   - Power it on or off.
9. **Speaker**
10. **Temperature sensor**
11. **Power jack**
12. **Wall mount slots**
13. **PAIR**
   - Press and hold for three seconds to enter pairing mode.
   - Reset the baby unit to factory default.
     1. Press and hold **PAIR** key until you hear a beep sound.
     2. Release the **PAIR** key, and then press the **PAIR** key again five times until you hear another beep sound.
     3. The baby unit will sound another beep when the reset completes. Then, the baby unit will reboot.

Parent unit overview

1. **LINK LED light**
   - On when the parent unit is linked to the baby unit.
   - Flashes when the link to the baby unit is lost.
2. **LED light**
   - On when the parent unit is connected to AC power, and the battery is charging.
   - Flashes when the parent unit battery is low and needs to be charged.
3. **3- level sound indicator light**
   - Green: low sound level is detected by the baby unit.
   - Green and amber: moderate sound level is detected by the baby unit.
   - Green, amber and red: high sound level is detected by the baby unit.
4. **TALK / ⟲**
   - Press and hold to talk to the baby unit.
   - While in a sub-menu, press to exit.
5. **MENU / SELECT**
   - Press to enter the main menu.
   - While in a menu, press to choose an item, or save a setting.
6. **◁△▷▽ Arrow keys**
   - Press to navigate leftward, upward, rightward or downward, within the main menu and sub-menus.
   - While viewing a zoomed image, press to move the image leftward, upward, rightward or downward.
7. **VOL – / VOL +**
   - Increase or decrease parent unit volume.
8. ⊕ **Zoom**
   - Press to zoom in/out.
   - While in a sub-menu, press to view the help menu.
9. ⏻ **Power | LCD ON/OFF**
10. **Microphone**
11. **Antenna**
12. **Speaker**
13. **Power jack**
14. **RESET**
   - Force reboot the parent unit.
15. **Stand**

TECHNICAL SPECIFICATIONS

Frequency	Baby unit: 2412 - 2472 MHz
Channels	13
LCD	7" Color LCD (IPS 1248x800 pixels)
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.
Power requirement	Parent unit power adapter: Output: 5V DC, 2A. Baby unit power adapter: Output: 5V DC, 1000mA. Parent unit battery: 3.7V 5000mAh, 18.5Wh Lithium-ion battery

DISCLAIMER AND LIMITATION OF LIABILITY

VTech Communications, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the use to our clients by third parties that may arise through the use of this product. VTech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product.
Company: VTech Communications, Inc.
Address: 9020 SW Washington Square Road – Ste 555 Tigard, OR 97223, United States
Phone: 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in Canada

Android™ and Google Play™ are trademarks of Google Inc.
App Store is a trademark of Apple Inc. registered in the U.S. and other countries.
iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Intertek 3177099 c US

Specifications are subject to change without notice.
© 2023 VTech Communications, Inc.
All rights reserved. 10/23. RM7766-XHD_CA_QSG_V5

HOW THE SYSTEM WORKS

Direct mode
Your baby monitor parent unit and baby unit connect to each other in Direct mode by default, which allows you to immediately stream video out of the box.
It is NOT recommended to continue using Direct Mode connection after initial installation.

Local access, for start up quick view and setup stage.

☼ **Tip**
You may experience reduced signal strength if your parent unit and baby unit are far apart, or there are obstructing factors, such as internal walls, between them. You have to set up **Router mode** to connect the units via your home Wi-Fi network to improve the connection between your parent unit and baby unit.

Router mode
You are required to set up your monitor in **Router mode** to enjoy live video streaming via your parent unit with an enhanced connection. **Router mode** is the recommended mode for stable streaming.

Router mode uses your home Wi-Fi network to connect your video monitor. It supports live video streaming through the parent unit and smartphone app.

If you want to stream live video remotely with your mobile device, download and install the **MyVTech Baby Pro** mobile app. With the mobile app, your Wi-Fi router (not included) provides Internet connectivity to your HD video monitor system. It serves as a communicating channel between your baby unit and mobile device, allowing you to monitor and/or control your baby unit wherever you are. For more details, see **Download app for mobile access** section in this quick start guide.

Note
- When both parent unit and app are viewing the camera simultaneously, the video quality will be optimised to deliver the best possible viewing result.

WiFi   Mobile access

Connecting Wi-Fi to enhance local access

PROTECT YOUR PRIVACY AND ONLINE SECURITY

VTech cares about your privacy and peace of mind. That's why we've put together a list of industry-recommended best practices to help keep your wireless connection private and your devices protected when online. We recommend you carefully review and consider complying with the following tips.

Ensure your wireless connection is secure.
- Before installing a device, ensure your router's wireless signal is encrypted by selecting the "WPA2-PSK with AES" setting in your router's wireless security menu.
Change default settings.
- Change your wireless router's default wireless network name (SSID) to something unique.
- Change default passwords to unique, strong passwords. A strong password:
  - Is at least 10 characters long.
  - Is complex.
  - Does not contain dictionary words or personal information.
  - Contains a mix of uppercase letters, lowercase letters, special characters and numbers.
Keep your devices up to date.
- Download security patches from manufacturers as soon as they become available. This will ensure you always have the latest security updates.
- If the feature is available, enable automatic updates for future releases.
Disable Universal Plug and Play (UPnP) on your router.
- UPnP enabled on a router can limit the effectiveness of your firewall by allowing other network devices to open inbound ports without any intervention or approval from you. A virus or other malware program could use this function to compromise security for the entire network.

For more information on wireless connections and protecting your data, please review the following resources from industry experts:
1. Federal Communications Commission: Wireless Connections and Bluetooth Security Tips
   www.fcc.gov/consumers/guides/how-protect-yourself-online.
2. U.S. Department of Homeland Security: Before You Connect a New Computer to the Internet –
   www.us-cert.gov/ncas/tips/ST15-003.
3. Federal Trade Commission: Using IP Cameras Safely –
   https://www.consumer.ftc.gov/articles/0382-using-ip-cameras-safely.
4. Wi-Fi Alliance: Discover Wi-Fi Security –
   http://www.wi-fi.org/discover-wi-fi/security.

CONNECT, CHARGE AND POWER ON THE BABY MONITOR

Connect the baby monitor

Notes
- The rechargeable battery in the parent unit is built-in.
- Use only the power adapters supplied with this product.
- Make sure the parent unit and the baby unit are not connected to the switch controlled electric outlets.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of the parent unit and the baby unit, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children.

Slide the switch to **ON** to power on your baby unit.

Notes
- When powering up, the baby unit's status LED turns on. It will turn off after a while and keeps off.
- The status LED is set to off by default. If you want to keep the LED on, press **MENU**, then go to ⚙ > **Status LED** and turn it on.

NOTE:
Camera lens and surface may get warm during normal operation.

Charge the parent unit battery before use
The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, keep the parent unit connected to AC power.

Notes
- Before using the baby monitor for the first time, charge the parent unit battery for 12 hours. When the parent unit battery is fully charged, the battery icon becomes solid.
- The standby time varies depending on your actual use.

The parent unit turns on automatically after connecting to the power socket, and the welcome screen appears. You can press ⏻ **Power** to turn the parent unit on or press and hold to turn it off.

LCD ON/OFF
Press and hold

The battery icon indicates the battery status (see the following table).

BATTERY INDICATORS	BATTERY STATUS	ACTION
The screen displays and the LED light flashes.	The battery has very little charge and may be used for only a short time.	Charge without interruption (about 30 minutes).
The battery icon becomes solid.	The battery is fully charged.	To keep the battery charged, connect it to AC power when in use.

Raise the parent unit antenna for better reception

PARENT UNIT ICONS

Main Menu	Options
Monitoring mode (* For **RM7766-2HD** only)	• View baby units in Single mode. • View baby units in Patrol mode. • View baby units in Split screen.
Night light	• Turn on or turn off night light. • Select a night light color. • Adjust night light brightness. • Set a night light timer.
Melodies and soothing sounds	• Select play all melodies, or play one of the five melodies and five soothing sounds. • You can also set the timer to stop playing after 15, 30 or 60 minutes, or playing non-stop. • Adjust baby unit speaker volume.
Alerts - Sound, motion and temperature	• Select the sound and motion sensitivity level. • Turn on/off sound and motion detection alerts. • Select maximum and minimum temperature for alert range. • Turn on/off temperature alert. • Turn on/off Auto Wake Up function.
Parent unit settings	• Adjust parent unit screen brightness. • Adjust Low Battery Alert Tone. • Adjust No Link Alert Tone. • Turn on/off Dim mode.
Baby unit settings	• Turn on/off Night Vision. • Turn on/off baby unit Status LED. • Adjust baby unit speaker volume. • Update baby unit security key.
General settings	• Connect to home Wi-Fi network. • Connect Mobile Phone. • **Reset settings** to factory default. • **Software Update**.

Status icons

|	
Direct mode	Parent unit, baby unit 1 and baby unit 2 (*For **RM7766-2HD** only) are connected to each others directly.
	Red bars indicate no connection.
Router mode	Parent unit, baby unit 1 and baby unit 2 (*For **RM7766-2HD** only) are connected to home Wi-Fi network.
	The red icon on the baby unit or parent unit, indicates no connection between the respective unit(s) and the router.
	Baby unit 1 and 2 are being viewed in **Patrol** mode (*For **RM7766-2HD** only).
	Baby unit 1 and 2 are being viewed in **Split** mode (*For **RM7766-2HD** only).
	Night vision is turned on.
	Motion detection alert is turned on.
	Sound detection alert is turned on.
	Melodies and soothing sounds are playing.
	Night light is turned on.
	Auto night light brightness is activated.
	Temperature alert is turned on.
	Parent unit is muted.
70°F °F	Temperature is lower than 68°F. Temperature is within 68°F and 75°F. Temperature is higher than 75°F.
	Battery indicator.

BASIC OPERATION

After powering up your video monitor, the parent unit streams live video in direct mode. We recommend you follow the instructions on screen to set up home Wi-Fi network with your monitor for functionality enhancements and mobile access. See **Auto software and firmware update** and **Download app for mobile access** in this quick start guide.

Use the menu

Press **MENU** on the parent unit to enter the main menu, choose a menu item, or save a setting. You can use the parent unit menu for advanced settings or operations, such as to play or stop the baby unit lullaby, or adjust the baby unit sound sensitivity.

While in the menu:
- Press ⟨/∧/⟩/∨ to scroll among the menu options.
- Press **SELECT** to select an item.
- Press **TALK** to return to the live video.
- Press ⊕ to go to the **Help & info** page.

Adjust speaker volume

Press **VOL −** | **VOL +** to adjust the parent unit speaker volume level received from the baby unit.

Zoom

Press ⊕ to zoom in or out in a fixed zoom sequence. ⊕ indicates that the image is magnified 3 times.

Muted

Talk to your baby via the baby unit

1. Press and hold the **TALK** key.
2. When the 🎤 icon displays on screen, speak to your parent unit. Your voice is transmitted to the baby unit.
3. When finished talking, release the **TALK** key to hear your baby again.

Press and hold

Turn on/off baby unit's status LED

Turn on or turn off the baby unit status LED indicator. Go to:

🔆 **> Status LED.**

Turn on/off the parent unit screen

You can turn on or turn off the parent unit screen without powering off the unit. You will still hear sounds from the baby unit.

- Press ⏻ | **LCD ON/OFF** on the parent unit to turn off the screen.
- Press any key on the parent unit to turn the screen on again.

☼ **TIP**
You can reset the parent unit by pressing the **RESET** key at the back of the unit.

Insert a pin into the **RESET** hole on the back of the parent unit, and then press the key inside.

NIGHT LIGHT

You can control the night light remotely on the parent unit or directly on the baby unit.

On the parent unit:

1. Press **MENU**.
2. Press ⟨ or ⟩ to scroll to 💡 **Night Light** menu, then press **MENU** or ∨ to enter.
3. Press ⟨ or ⟩ to choose below options:

💡	Turn on/off night light
🎨	Change night light color
🔆	Adjust night light brightness
⏲	Set night light timer

On the baby unit:

☼ **Night Light Control Key**

Single Tap: Turn on/off

Tap and hold: Adjust night light brightness

FOR RM7766-2HD ONLY

Monitoring Modes

When more than one baby unit is paired to the parent unit, you can choose to view different baby units in three monitoring modes. Learn more about each below:

Single Mode	[1] [2]	The screen displays images only from the selected baby unit in full screen.
Split Mode	[1][2]	The screen displays images from all paired baby units at the same time in split view.
Patrol Mode	[1]↻	The screen displays a single cam view that transitions to a different baby unit every 10 seconds.

Change the monitoring mode:

1. Press **MENU** when the baby unit is idle.
2. Press **MENU** or ∨ to enter 🔁 **Monitoring Mode** menu.
3. Press ⟨ or ⟩ to choose between **Single** [1][2], **Split** [1][2], and **Patrol** [1]↻ monitoring mode options. Press **SELECT** to confirm.


TEST THE SOUND LEVEL AND POSITION THE BABY MONITOR

Testing the sound level of the baby monitor

📝 **NOTE**
- This baby monitor is intended as an aid. It is not a substitute for proper adult supervision, and should not be used as such.

⚠ **CAUTION**
- For hearing protection, make sure the parent unit is more than 10 feet away from the baby unit. If you hear any feedback noise from the parent unit, move the parent unit further until the noise stops. You can also press **VOL −** on the parent unit to lower or mute the noise.

☼ **TIP**
- Increase the parent unit speaker volume if you cannot hear the sounds transmitted from the baby unit.

> 10ft

Positioning the baby monitor

⚠ **CAUTION**
- Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's crib or playpen.

1. Place the baby unit more than 3 feet away from your baby.
2. Adjust the angle of the baby unit to aim at your baby.

> 3ft (1m)

3. To avoid causing feedback noise from your baby monitor:
   - Make sure your baby unit and parent unit are more than 10 feet apart; OR
   - Turn down the volume of your parent unit.

✓ > 10ft (3m)

✗ < 10ft (3m)

TEST THE LOCATION FOR THE BABY UNIT

If you plan to install your baby unit in a designated location, and use your home Wi-Fi network to connect your video monitor, you need to test which of your selected monitoring areas within the house have good Wi-Fi signal strength. After you have powered on your parent unit, you can use your parent unit's Wi-Fi signal strength indicator to assist in checking. Once you have identified the suitable location, you can install your baby unit. Adjust the distance between your baby unit and the Wi-Fi router if needed.

☼ **TIP**
- Depending on surroundings and obstructing factors, such as the effect distance and internal walls have on signal strength, you may experience reduced Wi-Fi signal. To improve the Wi-Fi signal strength, adjust the distance or direction of your parent unit. Check with your parent unit again.

WiFi

AUTO SOFTWARE AND FIRMWARE UPDATE

To ensure that your HD video monitor is always at its best performance, the Parent Unit will prompt a message and ask you to update its software and the Baby Unit's firmware when there are new versions available. Select "Now" to reboot the system, or switch off and on the Parent Unit later to reboot the system into the latest software.

- To check if your device is running on the latest software, or to update your device software, go to:

  ⚙ **> Software Update.**

Connect your HD video monitor with home Wi-Fi network

- You must connect your video monitor to your secured home Wi-Fi network in order to receive the latest software and firmware updates. To set the Wi-Fi up, go to:

  ⚙ **> Configure Wi-Fi.**

📝 **NOTE**
- Make sure the Baby Unit is on when you set up the Wi-Fi network.

NEED HELP?

For operations and guides to help you use your video monitor, and for the latest information and support, check out our online help topics and online FAQs.

Use your smartphone or mobile device to access our online help.

- Go to **https://phones.vtechcanada.com/manuals**; OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to be redirected to the online help page.
  - If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.
- Search for the model – **RM7766HD** or **RM7766-2HD**.

You can also call our Customer Support at 1 (800) 267-7377 for help.

MOUNT THE BABY UNIT (OPTIONAL)

📝 **NOTES**
- Check for reception strength and camera angle of the baby unit before drilling the holes.
- The types of screws and plugs you need depend on the composition of the wall. You may need to purchase the screws and plugs separately to mount your baby units.

1. Place the wall mount bracket on a wall and then use a pencil to mark two holes in parallel. Remove the wall mount bracket and drill two holes in the wall (7/32 inch drill bit).

2. If you drill the holes into a stud, go to step 3.
   - If you drill the holes into an object other than a stud, insert the wall plugs into the holes. Tap gently on the ends with a hammer until the wall plugs are flush with the wall.

3. Align the wall mount bracket and screws with the holes in the wall as shown. Tighten the screw in the middle hole first, so that the wall mount bracket position is fixed. You can tighten the other screw in the top hole.

3. Insert the screws into the holes and tighten the screws until only 1/4 inch of the screws are exposed.

4. Place the baby unit on the wall mount bracket, and then slide it forward until it locks into place. Connect the power adapter to the baby unit and a power supply.

OR

4. Place the baby unit on the wall mount bracket, and then slide it forward until it locks into place. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it locks into place.

❶ ❷

5. You can maximize your baby unit's viewing angles by tilting the wall mount bracket. Hold the baby unit, and then rotate the knob in qn anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in a clockwise direction to tighten the joint and secure the angle.

GENERAL PRODUCT CARE

- Avoid placing it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose it to direct sunlight or moisture.
- Avoid dropping the product or treating it roughly.
- Clean with a soft damp cloth.
- DO NOT immerse the parent unit and the baby unit in water and do not clean them under running water.
- DO NOT use cleaning spray or liquid cleaners.
- Make sure the parent unit and the baby unit are dry before you connect them to the mains again.

STORAGE

When you are not going to use the video monitor for some time, store the parent unit, the baby unit and the adapters in a cool, dry place.

Q&A FREQUENTLY ASKED QUESTIONS

Below are the questions most frequently asked about the video monitor.

Can I turn the parent unit display screen off but keep hearing sounds from the baby unit?	Yes, press ⏻	**LCD ON/OFF** on the parent unit to turn off the screen. The parent unit display will also dim automatically after being inactive for some time. In both instances, you will still be able to hear all sounds from the baby unit. Press any key to turn the screen back on.
Why is the baby unit not responding normally?	Try the following (in the order listed) for a common cure: 1. Disconnect the power to the baby unit. 2. Wait a few minutes before reconnecting power back to the baby unit. 3. Reboot the parent unit.
Why is my screen in black and white?	The baby unit has a light sensor that measures ambient light. When the ambient light is dim, such as during night time or in a dark room, the baby unit activates its infrared LEDs, and displays the camera images in black and white night vision.
Why does my baby unit show offline? Why is the connection lost every now and then?	The baby unit may have lost connection to the Wi-Fi router. Check your network and router settings. Other electronic products may cause interference with your baby unit. Try installing your baby unit as far away from these electronic devices as possible.
Why can't I hear a sound/Why can't I hear my baby crying?	The parent unit speaker volume may be too low. Press **VOL +** on the parent unit to increase the volume. You may have set a low sound sensitivity level. Set the sound sensitivity to a higher level. For details, go to **www.vtechphones.com** for online help topics.

LIMITED WARRANTY

What does this limited warranty cover?

The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?

During the limited warranty period, VTech's authorized service representative will replace at VTech's option, without charge, a Materially Defective Product. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the replacement Products to you in working condition. You should expect the replacement to take approximately 30 days.

How long is the limited warranty period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase (90 days on products purchased as Refurbished"). This limited warranty also applies to the replacement Product for a period of either (a) 90 days from the date the replacement Product is shipped to you or (b) the time remaining on the original one-year warranty (90-day limited warranty on products that are purchased as Refurbished"); whichever is longer.

"Refurbished products purchased from our online store carry a 90-day replacement warranty.

What is not covered by this limited warranty?

This limited warranty does not cover:

1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
2. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or
3. Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or
4. Product to the extent that the problem is caused by use with non-VTech accessories; or
5. Product whose warranty quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or
6. Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
7. Product returned without a valid proof of purchase (see item 2 below); or
8. Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

How do you get warranty service?

To obtain warranty service in the USA, please visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.

NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit.

What must you return with the Product to get warranty service?

1. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
3. Provide your name, complete and correct mailing address, and telephone number.

Other limitations

This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification. State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please retain your original sales receipt as proof of purchase.

CABLE MANAGEMENT

1 2 3