

Go to www.vtechcanada.com for the latest VTech product news.

CS6929
CS6929-2
CS6929-26
CS6929-3
CS6929-4

DECT 6.0 cordless telephone



vtech

Abridged user's manual
(Canada version)

Congratulations

on purchasing your new VTech product. Before using this product, please read **Important safety instructions**.

This abridged user's manual provides you with basic installation and use instructions. A limited set of features are described in abbreviated form.


Please refer to the User's manual for a full set of installation and operation instructions at www.vtechcanada.com.




Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.

What's in the box

Your product package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.




1 set for CS6929
2 sets for CS6929-2/
CS6929-26
3 sets for CS6929-3
4 sets for CS6929-4



1 set for CS6929-2/
CS6929-26
2 sets for CS6929-3
3 sets for CS6929-4

Abridged user's manual

Handset overview




- Handset earpiece**
- LCD display**
- MENU/SELECT**
 - Show the menu.
 - Press and hold to select an item, or save an entry or setting.
- OFF/CANCEL**
 - Hang up a call.
 - Silence the ringer temporarily while the handset is ringing.
 - Press and hold to erase the missed call indicator while the phone is not in use.
 - Press to return to the previous menu; or press and hold to return to idle mode, without making changes.
- QUIET#**
 - Press repeatedly to show other dialing options when reviewing a caller ID log entry.
- INT**
 - Press to start an intercom conversation or transfer a call (for multi-handset models only).
- Microphone**
- MUTE/DELETE**
 - Mute the microphone during a call.
 - Delete digits or characters while using the dialing keys.
 - Silence the ringer temporarily while the handset is ringing.

9 -

- Make or answer a call using the handset speakerphone.
 - During a call, press to switch between the speakerphone and the handset earpiece.
- 10 - **TONE**
- While you have set the dial mode to pulse and on a call, press to switch to tone dialing temporarily.
- 11 - **OFF**
- Press to add a space when entering names.
- 12 - **1**
- Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or saving it to the phonebook.
 - Press and hold to set or dial your voicemail number.
- 13 - **TALK/FLASH**
- Make or answer a call.
 - Answer an incoming call when you hear a call waiting alert.
- 14 - **REDIAL/PAUSE**
- Press repeatedly to review the redial list.
 - Press and hold to insert a dialing pause while entering a number.
- 15 - **▲/VOLUME/**
- Review the phonebook when the phone is not in use.
 - Increase the listening volume during a call.
 - Scroll up while in a menu, phonebook, caller ID log, or redial list.
 - Move the cursor to the right when entering numbers or names.
- VOLUME/▼/CID**
- Review the caller ID log when the phone is not in use.
 - Decrease the listening volume during a call.
 - Scroll down while in a menu, phonebook, caller ID log, or redial list.
 - Move the cursor to the left when entering numbers or names.
- 16 - **CHARGE light**
- On when the handset is charging.


Telephone base overview



- Message window**
 - Shows the number of messages, and other information of the answering system or telephone base.
- PLAY/STOP**
 - Press to play messages.
 - Press to stop playing a message.
- REPEAT**
 - Press to repeat the playing message.
 - Press twice to play the previous message.
 - Press to skip to the next message.
- DELETE**
 - Press to delete the playing message.
 - When the phone is not in use, press twice to delete all old messages.
- +/VOL+**
 - Press to adjust the volume during message playback.
 - When the phone is not in use, press to adjust the telephone base ringer volume.
- ANS ON/OFF**
 - Press to turn the answering system on or off.
- FIND HANDSET**
 - Press to page all system handsets.
- ANS ON/OFF light**
 - On when the answering system is turned on.
- IN USE light**
 - Flashes when there is an incoming call, or another telephone sharing the same line is in use.
 - Flashes when handsets are being deregistered.
 - On when the handset is in use or being registered.
 - On when the answering system is answering a call.

- Speakerphone
- Charging pole

Charger overview



- Charging pole

Display icons overview

	The battery icon flashes when the battery is low and needs charging.
	The battery icon animates when the battery is charging.
	The handset ringer is turned off.
	There are new voicemail received from your telephone service provider.
	The message number currently playing and total number of new/old messages recorded.
ANS ON	The answering system is turned on.
ECO	The ECO mode activates automatically to reduce power consumption when the handset is within range from the telephone base.
NEW	There are new caller ID log entries.

Connect


You can choose to connect the telephone base for desktop use or wall mounting.

NOTES


- Use only the adapters provided.
- Make sure the electrical outlets are not controlled by wall switches.
- The adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

TIP


- If you subscribe to digital subscriber line (DSL) high-speed Internet service through your telephone line, make sure you install a **DSL filter** (not included) between the telephone line cord and telephone wall jack. Contact your DSL service provider for more information.



Connect the telephone base




Connect the charger




Mount the telephone base


- Connect the telephone line cord to the telephone base. Route it through the wall mount bracket, and then connect it to the wall jack.




- Align and place the wall mount bracket on the standard wall plate.



- Align and place the telephone base on the wall mount bracket. Slide it down until it clicks securely in place.



- Connect the power adapter.






Install and charge the battery

Install the battery

Install the battery as shown below.


NOTES

- Use only the battery provided.
- Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual.
- The handset will not be used for a long time, disconnect and remove the battery to prevent possible leakage.



Charge the battery

Place the handset in the telephone base or the charger to charge.



Once you have installed the battery, the handset LCD display indicates the battery status (see the table below).

NOTES

- For best performance, keep the handset in the telephone base or charger when not in use.
- The battery is fully charged after 12 hours of continuous charging.

Battery indicators	Battery status	Action
The screen is blank, or shows Put in charger and	The battery has no charge or very little charge. The handset cannot be used.	Charge without interruption (at least 30 minutes).
The screen shows Low battery and	The battery has enough charge to be used for a short time.	Charge without interruption (at least 30 minutes).
The screen shows HANDSET X .	The battery is charged.	To keep the battery charged, place it in the telephone base or charger when not in use.

Before use

After you install your telephone or power returns following a power outage, the handset will prompt you to set the date and time, and the answering system through voice guide.

Set date and time

NOTE

- Make sure you set the date and time including the year correctly; otherwise the answering system does not announce the correct day of the week for your recorded messages time stamp.

- Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press **SELECT**.
- Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press **▼** or **▲** to choose **AM** or **PM**.
- Press **SELECT** to save.

Set answering system through voice guide

This feature assists you to do the basic setup of the answering system. You can follow the voice guide to record your own announcement, set the number of rings and the message alert tone.

- Press **SELECT** to start the voice guide for the answering system setup. You hear the voice prompt "Hello! This voice guide will assist you with the basic setup of your answering system."
- Setup your answering system by inputting the designated numbers as instructed in the voice guide.

Check for dial tone

Press **▲**. If you hear a dial tone, the installation is successful.

If you do not hear a dial tone:

- Make sure the installation procedures described above are properly done.
- It may be a wiring problem. If you have changed your telephone service to digital service from a cable company or a VoIP service provider, the telephone line may need to be rewired to allow all existing telephone jacks to work. Contact your cable/VoIP service provider for more information.

Operating range

This cordless telephone operates with the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and telephone base can communicate over only a certain distance - which can vary with the locations of the telephone base and handset, the weather, and the layout of your home or office.

When the handset is out of range, the handset displays **Out of range or no pwr at base**.

If there is a call while the handset is out of range, it may not ring, or if it does ring, the call may not connect well when you press **▲**. Move closer to the telephone base, and then press **▲** to answer the call. If the handset moves out of range during a telephone conversation, there may be interference. To improve reception, move closer to the telephone base.

Using the handset menu

- Press **MENU** when the phone is not in use.
- Press **▼** or **▲** until the screen displays the desired feature menu.
- Press **SELECT** to enter that menu.
- To return to the previous menu, press **CANCEL**.
- To return to idle mode, press and hold **CANCEL**.

Configure your telephone


Set language

The LCD language is preset to English. You can select English, French or Spanish to be used in all screen displays.

- Press **MENU** when the handset is not in use.
- Scroll to **Settings**, and then press **SELECT** twice.
- Scroll to choose **English**, **Français** or **Español**, and then press **SELECT** to save.

Telephone operation

Handset control key panel:



Make a call

- Press **▲** or **▲**, and then dial the telephone number.

Answer a call

- Press **▲**, **▲**, or any dialing key.

End a call

- Press **OFF** on the handset, or put the handset into the telephone base or charger.

Speakerphone

- During a call, press **▲** on the handset to switch between speakerphone and handset earpiece.

Volume

- During a call, press **▲/VOLUME/▲** on the handset to adjust the listening volume.

NOTE

- The handset earpiece volume setting and speakerphone volume setting are independent.

Mute

The mute function allows you to hear the other party but the other party cannot hear you.

- During a call, press **MUTE** on the handset. The screen displays **Muted**.
- Press **MUTE** again to resume the conversation. The screen displays **Microphone on**.

Join a call in progress

You can use up to two system handsets at a time on an outside call.

- When a handset is already on a call, press **▲** or **▲** on another handset to join the call.
- Press **OFF** or place the handset in the telephone base or charger to exit the call. The call continues until all handsets hang up.

Call waiting

When you subscribe to call waiting service from your telephone service provider, you hear an alert tone if there is an incoming call while you are on another call.

- Press **FLASH** to put the current call on hold and take the new call.
- Press **FLASH** to switch back and forth between calls.

Find handset

Use this feature to find all system handsets.

To start paging:

- Press **FIND HANDSET** on the telephone base. All idle handsets ring and display "Paging".

To end paging:

- Press **FIND HANDSET** again on the telephone base.

- Press **▲**, **▲**, **OFF**, or any dialing key on the handset.
- Place the handset in the telephone base or charger.

NOTE

- Do not press and hold **FIND HANDSET** for more than four seconds. It may lead to handset deregistration.

Redial list

Each handset stores the last 10 telephone numbers dialed. When there are already 10 entries, the oldest entry is deleted to make room for the new entry.

Review the redial list

- Press **REDIAL** when the handset is not in use.
- Press **▼**, **▲**, or **REDIAL** repeatedly until the desired entry displays.

Dial a redial list entry

- When the desired entry displays, press **▲** or **▲** to dial.

Delete a redial list entry

- When the desired redial entry displays, press **DELETE**.

Intercom

Use the intercom features for conversations between two handsets.

- Press **INT** on your handset when not in use. Use the dialing keys to enter a destination handset number if necessary.
- To answer the intercom call, press **▲**, **▲**, or any dialing key on the destination handset.
- To end the intercom call, press **OFF** or place the handset back in the telephone base or charger.

Phonebook

The phonebook can store up to 50 entries, which are shared by all handsets. Each entry may consist of a telephone number up to 30 digits, and a name up to 15 characters.

- When the desired entry appears, press **▲** or **▲** to dial.

Delete a phonebook entry

- When the desired entry displays, press **DELETE**.

Edit a phonebook entry

- When the desired entry appears, press **▲** or **▲** to dial.

Caller ID

If you subscribe to caller ID service, information about each caller appears after the first or second ring. If you answer a call before the caller information appears on the screen, it will not be saved in the caller ID log.

The caller ID log stores up to 30 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name.

If the telephone number has more than 15 digits, only the last 15 digits appear. If the name has more than 15 characters, only the first 15 characters are shown and saved in the caller ID log.

Review a caller ID log entry

- Press **CID** when the phone is not in use.
- Scroll to browse through the caller ID log.

Missed call indicator

When there are calls that have not been reviewed in the caller ID log, the handset displays **XX missed calls**.

Each time you review a caller ID log entry marked **NEW**, the number of missed calls decreases by one.

When you have reviewed all the missed calls, the missed call indicator no longer displays.

If you do not want to review the missed calls one by one, press and hold **CANCEL** on the idle handset to erase the missed call indicator. All the entries are then considered old.

Dial a caller ID log entry

- When the desired entry appears, press **▲** or **▲** to dial.

Save a caller ID log entry to the phonebook

- When the desired caller ID log entry displays, press **SELECT**.
- Press **SELECT** to choose **To Phonebook**.
- Use the dialing keys to modify the number, and then press **SELECT**.
- Use the dialing keys to modify the name, and then press **SELECT** to save.

Delete a caller ID log entry

- When the desired caller ID log entry displays, press **DELETE**.

Delete all caller ID log entries

- Press **MENU** when the phone is not in use.
- Scroll to **Caller ID log** and then press **SELECT**.
- Scroll to **Delete all** and then press **SELECT** twice.

Call block

If you have subscribed to caller ID service, you can set the telephone to block unknown calls and certain undesired calls. The call block list can store up to 20 entries.

Block unknown calls

- Press **MENU** when the handset is not in use.
- Scroll to **Call block**, and then press **SELECT**.
- Scroll to choose **Calls w/o num**, and then press **SELECT**.
- Scroll to choose **Unblock** or **Block**, and then press **SELECT** to save.

Add a call block list entry

- Press **MENU** when the handset is not in use.
- Scroll to **Call block**, and then press **SELECT**.
- Press **SELECT** to choose **Block list**.
- Scroll to choose **Add new entry**, and then press **SELECT**.
- Use the dialing keys to enter the number (up to 30 digits).
- Press **SELECT** to move to enter the name.
- Use the dialing keys to enter the name (up to 15 characters). Additional key presses show other characters of that particular key.
- Press **SELECT** to save.

Review call block list

- Press **MENU** when the handset is not in use.
- Scroll to **Call block**, and then press **SELECT**.
- Press **SELECT** to choose **Block list**.
- Press **SELECT** to choose **Review**.

Edit a call block list entry

- When the desired entry displays, press **SELECT**.
- Use the dialing keys to edit the number, and then press **SELECT**.
- Use the dialing keys to edit the name, and then press **SELECT** to save.

Save a caller ID log entry to call block list

- When the desired entry displays, press **SELECT**.
- Scroll to **To Call block**, and then press **SELECT**.

- Use the dialing keys to modify the number, and then press **SELECT**.
- Use the dialing keys to modify the name, and then press **SELECT** to save.

Delete a call block list entry

- When the desired call block list entry displays, press **DELETE**.

Mute rings of blocked calls

An incoming call will ring once and then the system will check if the call should be blocked. You can mute the first ring of blocked calls.

- Press **MENU** when the handset is not in use.
- Press **7464#** on the handset.
- Scroll to choose **First ring:On** or **First ring:Off**, and then press **SELECT**.

Sound settings

Key tone

You can turn the key tone on or off.

- Press **MENU** when the handset is not in use.
- Scroll to **Settings**, and then press **SELECT**.
- Scroll to choose **Key tone**, and then press **SELECT**.
- Scroll to choose **On** or **Off**, and then press **SELECT** to save.

Ringer tone

You can choose from different ringer tones for each handset.

- Press **MENU** when the handset is not in use.
- Scroll to **Ringers**, and then press **SELECT**.
- Scroll to choose **Ringer tone**, and then press **SELECT**.
- Scroll to sample each ringer tone, and then press **SELECT** to save.

NOTE

- If you turn off the ringer volume, you will not hear ringer tone samples.

Handset r

About answering system and voicemail service

For message recording, your telephone has a built-in answering system, and it also supports voicemail service offered by your telephone service provider (subscription is required, and fee may apply).
The main differences between them are:

Category	Built-in answering system	Voicemail from telephone service
Storage	Messages are stored in the telephone base. Your messages will not be deleted automatically. You have to delete your messages manually.	Messages are stored in a server or system provided by your telephone service. Your messages may be automatically deleted after a period of time. Contact your telephone service provider for more details.
Method to retrieve messages	When you received new messages, handset displays XX new messages and the message window on the telephone base flashes. To retrieve messages, usually there are two ways: <ul style="list-style-type: none">Press ■ on the telephone base; orAccess remotely with an access code.	When you received new messages, the handset displays ■ and New voicemail . To retrieve messages, you need an access number and/or a passcode provided by your telephone service provider.

Set your built-in answering system

The answering system can record and store up to 99 messages. Each message can be up to three minutes in length. The total storage capacity for the announcement, messages and memos is approximately 23 minutes. The actual recording time depends on individual message characteristics.

Your answering system allows you to set the voice prompt language and your announcement, to save and delete messages, activate call screening, to set number of rings before pick up, and to access remotely.

Telephone base control key panel:

- Turn the answering system on or off
- The answering system must be turned on to answer and record messages.
- To turn on or off with the telephone base:
- Press **Q/ANS ON** on the telephone base to turn the built-in answering system on or off.
- To turn on or off with the handset:
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys**, and then press **SELECT**.
 - Scroll to **Answer on/off**, and then press **SELECT**.
 - Scroll to **On or Off**, and then press **SELECT** to save. You hear a confirmation tone.

- Do not overload wall outlets and extension cords.
 - Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
 - When the power supply cord or plug is damaged or frayed.
 - If liquid has been spilled onto the product.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and often requires extensive work by an authorized technician to restore the product to normal operation.
 - If the product has been dropped and the telephone base and/or handset has been damaged.
 - If the product exhibits a distinct change in performance.
 - Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning.
 - Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not put a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.
 - Only put the handset of your telephone next to your ear when it is in normal talk mode.
 - The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-cabinet table or cabinet outlet.
 - For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.
- SAVE THESE INSTRUCTIONS

- Set your built-in answering system
- The voice prompt language is preset to English. You can select English or French to be used for the voice prompts in your answering system.
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** and then press **SELECT**.
 - Scroll to **Ans sys setup** and then press **SELECT**.
 - Scroll to **Voice language** and then press **SELECT**.
 - Scroll to choose **English** or **Français**.
 - Press **SELECT** to save and you hear a confirmation tone.
- Default announcement
- The telephone is preset with a greeting that answers calls with "*Hello, please leave a message after the tone*". You can use this preset announcement, or replace it with your own.
- Record your own announcement
- The announcement can be up to 90 seconds in length.
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** and then press **SELECT** twice.
 - The handset displays **Play [2] Del [3] Rec [7]**, and it announces, "*To play, press 2. To record, press 7.*"
 - Press **7** to record. The handset announces, "*Record after the tone. Press 5 when you are done*". After the tone, speak towards the handset microphone. Then, press **5** when done.
- Play the announcement
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** and then press **SELECT** twice.
 - The handset displays **Play [2] Del [3] Rec [7]**, and it announces, "*To play, press 2. To record, press 7.*"
 - Press **2** to play the announcement.
- Delete the announcement
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** and then press **SELECT** twice.
 - The handset displays **Play [2] Del [3] Rec [7]**, and it announces, "*To play, press 2. To record, press 7.*"
 - Press **3** to delete your own recorded announcement.

- Remote access
- You can set the answering system to answer an incoming call after two, three, four, five or six rings; or toll saver. If you choose toll saver, the answering system answers a call after two rings when you have new messages, or after four rings when you have no new messages.
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** then press **SELECT**.
 - Scroll to **Ans sys setup** then press **SELECT**.
 - Scroll to **# of rings** then press **SELECT**.
 - Scroll to choose **2, 3, 4, 5, 6** or **Toll saver**.
 - Press **SELECT** to save and you hear a confirmation tone.
- Set message alert tone
- When the message alert tone is set to on, and there is at least one new message, the telephone base beeps every 10 seconds. The message alert tone is preset to off.
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** then press **SELECT**.
 - Scroll to **Ans sys setup** then press **SELECT**.
 - Scroll to choose **Tone: On or Tone: Off**.
 - Press **SELECT** to save and you hear a confirmation tone.
- Voice guide
- This feature is an alternative way for you to do the basic setup of the answering system. You can follow the voice guide to record your own announcement, set the number of rings and the message alert tone.
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** and then press **SELECT**.
 - Scroll to **Voice guide**, and then press **SELECT**. You hear the voice prompt "*Hello! This voice guide will assist you with the basic setup of your answering system*".
 - Setup your answering system by inputting designated numbers as instructed in the voice guide.

- Use your built-in answering system
- New message indication
- When there are new answering system messages, The handset displays **XX new messages** and the message window on the telephone base flashes.
- Message playback
- To playback messages at the telephone base:
- Press **►/PLAY** when the phone is not in use.
- Options during playback:
- Press **VOL+** or **VOL-** to adjust the speaker volume.
 - Press **►/SKIP** to skip to the next message.
 - Press **◄/REPEAT** to repeat the message currently playing. Press **◄/REPEAT** twice to listen to the previous message.
 - Press **X/DELETE** to delete the playing message. The system advances to the next message.
 - Press **►/STOP** to stop.
- To playback messages with a handset:
- Press **MENU** when the phone is not in use, and then press **SELECT**.
- Options during playback:
- Press **▼/VOLUME/▲** to adjust the message playback volume.
 - Press **6** to skip to the next message.
 - Press **4** to repeat the message. Press **4** twice to listen to the previous message.
 - Press **3** to delete the playing message.
 - Press **OFF** to stop the playback.
 - Press **◄/►** to switch between speakerphone and handset earpiece.
- Delete all messages
- You can only delete old (reviewed) messages. You cannot delete new messages until you review them. You cannot retrieve deleted messages.
- To delete all messages with the telephone base:
- Press **X/DELETE** twice when the phone is not in use.
- To delete all messages with a handset:
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys**, and then press **SELECT**.
 - Scroll to **Ans sys setup** then press **SELECT**.
 - Scroll to **Remove code**, and then press **SELECT**.
 - Use the dialing keys to enter a two-digit number. **-OR-** Scroll to a desired two-digit number.
 - Press **SELECT** to save and you hear a confirmation tone.

- Remote access code
- You can set your own remote access code from **00 to 99**.
- Press **MENU** when the phone is not in use.
 - Scroll to **Answering sys** then press **SELECT**.
 - Scroll to **Ans sys setup** then press **SELECT**.
 - Scroll to **Remote code**, and then press **SELECT**.
 - Use the dialing keys to enter a two-digit number. **-OR-** Scroll to a desired two-digit number.
 - Press **SELECT** to save and you hear a confirmation tone.
4. Hang up or press **8** to end the call.

- Use the built-in answering system and voicemail service
- You can use your answering system and voicemail service together by setting your answering system to answer before voicemail service answers as described below. To learn how to program your voicemail settings, contact your telephone service provider.
- If you are on a call, or if the answering system is busy recording a message and you receive another call, the second caller can leave a voicemail message.
- Set your answering system to answer calls at least two rings earlier than your voicemail service is set to answer. For example, if your voicemail service answers after six rings, set your answering system to answer after four rings. Some voicemail service providers may program the delay before answering calls in seconds instead of rings. In this case, allow six seconds per ring when determining the appropriate setting.
- Retrieve voicemail from telephone service
- Voicemail is a feature available from most telephone service providers. It may be included with your telephone service, or may be optional. Fees may apply.
- Retrieve voicemail
- When you received a voicemail, the handset displays **■** and **New voicemail**. To retrieve, you typically dial an access number provided by your telephone service provider, and then enter a security code. Contact your telephone service provider for instructions on how to configure the voicemail settings and listen to messages.
- NOTE
- After you have listened to all new voicemail messages, the indicators on the handset turn off automatically.
- Set your voicemail number
- You can save your access number on each handset for easy access to your voicemail. After you saved the voicemail number, you can **press and hold** **■** **1** to retrieve voicemail.
- Press **MENU** when the handset is not in use.
 - Scroll to **Settings** and then press **SELECT**.
 - Scroll to **Voicemail #** and then press **SELECT**.
 - Use the dialing keys to enter the voicemail number (up to 30 digits).
 - Press **SELECT** to save.

- ECO mode
- This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base.
- NOTE
- This feature turns off the indicators only; it does not delete your voicemail messages.
- Press **MENU** when the handset is not in use.
 - Scroll to **Settings**, and then press **SELECT**.
 - Scroll to **Cir voicemail**, and then press **SELECT**. You hear a confirmation tone.
- Expand your telephone system
- You can add new handsets (**CS6909**), cordless headsets (**IS6200**) or speakerphones (**MA3222** or AT&T **TL80133**) to your telephone system. All accessories are sold separately. Your telephone base supports a maximum of five devices.
- For more details, refer to the user's manual that comes with your new device.

- Frequently asked questions
- Below are the questions most frequently asked about the cordless telephones. If you cannot find the answer to your question, visit our website at www.vtechcanada.com or call **1 (800) 267-7377**.
- | | |
|--|--|
| My telephone does not work at all. | Make sure the telephone base is installed properly, and battery is installed and charged correctly. For optimum daily performance, return the handset to the telephone base after use. |
| The display shows No line . I cannot hear the dial tone. | Disconnect the telephone line cord from your telephone and connect it to another telephone. If there is no dial tone on that other telephone either, then the telephone line cord may be defective. Try installing a new telephone line cord. If changing telephone line cord does not help, the wall jack (or the wiring to this wall jack) may be defective. Contact your telephone service provider. |
| The answering system does not announce the correct day of the week for recorded messages time stamp. | Make sure you have set the date and time. See Configure your telephone section. |
| The messages on the answering system are incomplete. | If a caller leaves a very long message, part of it may be lost when the answering system disconnects the call after the preset recording time. |
| The display shows To register HS... and ...see manual alternately. The handset does not work at all. | If the memory on the answering system becomes full during a message, the answering system stops recording and disconnects the call.

You may be using a new cable or VoIP service, the existing telephone jacks in your home may no longer work. Contact your service provider for solutions.

The handset shows Registered and you hear a beep when the registration process completes. This process takes about 90 seconds to complete. |

- Important safety instructions
- When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:
- Read and understand all instructions.
 - Follow all warnings and instructions marked on the product.
 - Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
 - Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub or swimming pool, or in a wet basement or shower.
 - Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
 - Avoid placing the telephone system in places with extreme temperature, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids and fumes.
 - Slots and openings in the back or bottom of the telephone base and handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area where proper ventilation is not provided.
 - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or office, consult your dealer or local power company.
 - Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on.
 - Never push objects of any kind into this product through the slots in the telephone base or handset because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
 - To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the telephone base or handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.

Technical specifications	
Frequency control	Crystal controlled PLL synthesizer
Transmit frequency	Handset: 1921.536-1928.448 MHz Telephone base: 1921.536-1928.448 MHz
Channels	5
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environment conditions at the time of use.
Power requirements	Handset: 2.4V Ni-MH battery Telephone base: 6V DC @ 400mA Charger: 6V AC @ 300mA
Memory	Phonebook: 50 memory locations; up to 30 digits and 15 characters Caller ID log: 30 memory locations; up to 24 digits and 15 characters

- What must you return with the Product to get warranty service?
- Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
 - Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
 - Provide your name, complete and correct mailing address, and telephone number.
- Other limitations
- This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no authorized service representatives of VTech; or modifications to this limited warranty and you should not rely on any such modification.
- State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.
- Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation purposes (including but not limited to Products used for rental purposes); or
- Product returned without a valid proof of purchase (see item 2 on the next page); or
- Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.
- How do you get warranty service?
- To obtain warranty service, please visit our website at www.vtechcanada.com or call **1 (800) 267-7377**. NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call.
- Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase cannot meet the requirements of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty.
- What is not covered by this limited warranty?
- This limited warranty does not cover:
- Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
 - Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or
 - Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or
 - Product to the extent that the problem is caused by use with non-VTech accessories; or
 - Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or
 - Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
 - Product returned without a valid proof of purchase (see item 2 on the next page); or
 - Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.
- What does this limited warranty cover?
- The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

- FCC, ACTA and IC regulations
- FCC Part 15
- This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Privacy of communications may not be ensured when using this telephone.
- To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The handset may be safely held against the ear of the user. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20 cm (8 inches) or more.
- This Class B digital apparatus complies with Canadian requirements.
- CAN ICES-3 (B)/NMB-3(B)

- FCC Part 68 and ACTA
- This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US:AAAEQ##TXXXX. This identifier must be provided to your telephone service provider upon request.
- The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line and an RJ14 jack for two lines. See the installation instructions in the user's manual.
- The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, contact your telephone service provider.
- This equipment may not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone service provider or a qualified installer.
- If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents. For repair procedures, follow the instructions outlined under the Limited warranty.
- If this equipment is causing harm to the telephone network, the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone service provider is required to inform you of your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned.
- If this product is equipped with a corded or cordless handset, it is hearing aid compatible. If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency numbers, please:
- Remain on the line and briefly explain the reason for the call before hanging up.
 - Perform such activities in off-peak hours, such as early morning or late evening.

- Industry Canada
- This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Privacy of communications may not be ensured when using this telephone.
- The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.
- The Ringer Equivalence Number (REN) for this terminal equipment is 1.0. The REN indicates the maximum number of devices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.
- This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.
- Limited warranty
- What does this limited warranty cover?
- The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

- What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?
- During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the repaired or replacement Product to you in working condition. You should expect the repair or replacement to take approximately 30 days.
- How long is the limited warranty period?
- The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech repairs or replaces a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to the repaired or replacement Product for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining on the original one-year warranty; whichever is longer.
- What is not covered by this limited warranty?
- This limited warranty does not cover:
- Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
 - Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or
 - Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or
 - Product to the extent that the problem is caused by use with non-VTech accessories; or
 - Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or
 - Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
 - Product returned without a valid proof of purchase (see item 2 on the next page); or
 - Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.
- How do you get warranty service?
- To obtain warranty service, please visit our website at www.vtechcanada.com or call **1 (800) 267-7377**. NOTE: Before calling for service, please review the

- Specifications
- | | |
|-------------------------|--|
| Frequency control | Crystal controlled PLL synthesizer |
| Transmit frequency | Handset: 1921.536-1928.448 MHz
Telephone base: 1921.536-1928.448 MHz |
| Channels | 5 |
| Nominal effective range | Maximum power allowed by FCC and IC. Actual operating range may vary according to environment conditions at the time of use. |
| Power requirements | Handset: 2.4V Ni-MH battery
Telephone base: 6V DC @ 400mA
Charger: 6V AC @ 300mA |
| Memory | Phonebook: 50 memory locations; up to 30 digits and 15 characters
Caller ID log: 30 memory locations; up to 24 digits and 15 characters |

- Technical specifications
- | | |
|-------------------------|--|
| Frequency control | Crystal controlled PLL synthesizer |
| Transmit frequency | Handset: 1921.536-1928.448 MHz
Telephone base: 1921.536-1928.448 MHz |
| Channels | 5 |
| Nominal effective range | Maximum power allowed by FCC and IC. Actual operating range may vary according to environment conditions at the time of use. |
| Power requirements | Handset: 2.4V Ni-MH battery
Telephone base: 6V DC @ 400mA
Charger: 6V AC @ 300mA |
| Memory | Phonebook: 50 memory locations; up to 30 digits and 15 characters
Caller ID log: 30 memory locations; up to 24 digits and 15 characters |

- What must you return with the Product to get warranty service?
- Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
 - Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
 - Provide your name, complete and correct mailing address, and telephone number.
- Other limitations
- This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no authorized service representatives of VTech; or modifications to this limited warranty and you should not rely on any such modification.
- State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.
- Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation purposes (including but not limited to Products used for rental purposes); or
- Product returned without a valid proof of purchase (see item 2 on the next page); or
- Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.
- How do you get warranty service?
- To obtain warranty service, please visit our website at www.vtechcanada.com or call **1 (800) 267-7377**. NOTE: Before calling for service, please review the